PIAA

YEAR (Range)									SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2001	2003	Acura	CL	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2001	2003	Acura	CL	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1997	1999	Acura	CL	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	1999	Acura	CL	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2008	2011	Acura	CSX	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2011	Acura	CSX	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2005	Acura	EL	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2001	2005	Acura	EL	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2000	Acura	EL	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2000	Acura	EL	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	1998	Acura	EL	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	1998	Acura	EL	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	1998	Acura	EL	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2013	2018	Acura	ILX	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2018	Acura	ILX	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1994	2001	Acura	Integra	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	2001	Acura	Integra	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	2001	Acura	Integra	-	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1990	1993	Acura	Integra	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1990	1993	Acura	Integra	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1990	1993	Acura	Integra	-	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1989	Acura	Integra	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1989	Acura	Integra	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1995	Acura	Legend	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	1995	Acura	Legend	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1990	Acura	Legend	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1986	1990	Acura	Legend	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2014	2018	Acura	MDX	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2014	2018	Acura	MDX	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2014	2018	Acura	MDX	-	Rear	Hybrid	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2007	2013	Acura	MDX	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2007	2013	Acura	MDX	-	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2001	2006	Acura	MDX	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2001	2006	Acura	MDX	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1991	2005	Acura	NSX	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	2005	Acura	NSX	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2016	2018	Acura	RDX	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Acura	RDX	-	Passenger Side	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2007	2015	Acura	RDX	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	need 94005	Side Mount Hook	26"
2007	2015	Acura	RDX	-	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	need 94005	Side Mount Hook	16"
1996	2004	Acura	RL	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1996	2004	Acura	RL	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2014	2018	Acura	RLX	-	Driver Side	Beam	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2014	2018	Acura	RLX	-	Passenger Side	Beam	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2002	2006	Acura	RSX	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2006	Acura	RSX	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2002	2006	Acura	RSX	-	Rear	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1999	Acura	SLX	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1999	Acura	SLX	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2004	2014	Acura	TL	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2004	2014	Acura	TL	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1995	2003	Acura	TL	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1995	2003	Acura	TL	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2015	2018	Acura	TLX	-	Driver Side	Beam	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2015	2018	Acura	TLX	-	Passenger Side	Beam	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2009	2014	Acura	TSX	-	Driver Side	Hybrid	Hook 9x3	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2009	2014	Acura	TSX	-	Passenger Side	Hybrid	Hook 9x3	97055	V	-	-	96155	Need 94005	Side Mount Hook	22"
2004	2008	Acura	TSX	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2004	2008	Acura	TSX	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	1994	Acura	Vigor	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1992	1994	Acura	Vigor	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2010	2013	Acura	ZDX	-	Driver Side	Hybrid	Hook slot 9x3/9x4	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2013	Acura	ZDX	-	Passenger Side	Hybrid	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1995	Alfa Romeo	164	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2016	2018	Alfa Romeo	Giulia	-	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2016	2018	Alfa Romeo	Giulia	-	Passenger Side	Beam	Narrow PTB	97045	B	-	-	-	-	-	18"
1981	1986	Alfa Romeo	GTV-6	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1987	1989	Alfa Romeo	Milano	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1971	1994	Alfa Romeo	Spider, Spider Veloce	Convertible	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1980	1987	American Motors	Eagle	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1984	1986	American Motors	Encore	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1975	1980	American Motors	Pacer	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1975	1980	American Motors	Pacer	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1997	2004	Aston Martin	DB7	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2005	2011	Aston Martin	DB9	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2011	Aston Martin	DB9	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2008	2011	Aston Martin	DBS	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2008	2011	Aston Martin	DBS	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2010	2011	Aston Martin	Rapide	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2011	Aston Martin	Rapide	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2006	2007	Aston Martin	Vanquish	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2006	2011	Aston Martin	V8 Vantage	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2011	Aston Martin	V8 Vantage	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2010	2011	Aston Martin	V12 Vantage	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2011	Aston Martin	V12 Vantage	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1993	Asuna	GT	Canada	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1993	Asuna	SE	Canada	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1994	Asuna	Sunfire	Canada	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1994	Asuna	Sunfire	Canada	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	1994	Asuna	Sunrunner	Canada	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1988	1992	Audi	80	Inc. Quattro	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1988	1995	Audi	90	Inc. Quattro	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1994	Audi	100	Inc. Quattro	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1992	1994	Audi	100	Inc. Quattro	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1992	1994	Audi	100	Inc. Quattro, Wagon	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1991	Audi	100	Inc. Quattro	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1989	1991	Audi	100	Inc. Quattro, Wagon	Rear	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1970	1977	Audi	100	Inc.GL,LS	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1989	1991	Audi	200	Inc. Quattro	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1989	1991	Audi	200	Inc. Quattro, Wagon	Rear	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1985	1987	Audi	4000	Inc. Quattro, GT Coupe	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1985	1987	Audi	4000	Inc. Quattro, GT Coupe	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1984	1984	Audi	4000	Inc. Quattro, GT Coupe	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1984	1984	Audi	4000	Inc. Quattro, GT Coupe	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1980	1983	Audi	4000	Inc. Quattro, GT Coupe	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1984	1988	Audi	5000	Inc. Turbo	Front & Rear	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1978	1983	Audi	5000	Inc. Turbo	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2014	2017	Audi	A3	Inc. e-tron	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2014	2017	Audi	A3	Inc. e-tron	Passenger Side	Beam	Narrow PTB	97045	B	-	-	-	-	-	18"
2006	2013	Audi	A3	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2006	2013	Audi	A3	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2009	2018	Audi	A4	Sedan & Avant	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2009	2018	Audi	A4	Sedan & Avant	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2016	2018	Audi	A4	Quattro Wagon	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2016	2018	Audi	A4	Quattro Wagon	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
1996	2001	Audi	A4	Sedan & Avant	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1996	2001	Audi	A4	Sedan & Avant	Passenger Side	Conv	Hook slot 9x4	97050	V	95050	C3	-	-	-	20"
1998	2001	Audi	A4	Sedan & Avant	Rear		Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2009	2018	Audi	A5	Coupe, Convertible & Cabriolet	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2009	2018	Audi	A5	Coupe, Convertible & Cabriolet	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2011	2018	Audi	A6	-	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2011	2018	Audi	A6	-	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2006	2010	Audi	A6	-	Rear		Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2002	2005	Audi	A6	-	Rear		Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1999	2001	Audi	A6	-	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1999	2001	Audi	A6	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1999	2001	Audi	A6	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1995	1998	Audi	A6	-	Driver Side		Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1998	Audi	A6	-	Passenger Side		Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1998	Audi	A6	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2018	Audi	A7	-	Driver side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2012	2018	Audi	A7	-	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2015	2016	Audi	A8	Incl L	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2015	2016	Audi	A8	Incl L	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2011	2016	Audi	A8 Quattro	Inc. L, L W12	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2011	2016	Audi	A8 Quattro	Inc. L, L W12	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
1997	2002	Audi	A8	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	2002	Audi	A8	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2013	2018	Audi	allroad	-	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2013	2018	Audi	allroad	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2001	2003	Audi	Allroad Quattro	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C3	-	-	-	22"
2001	2003	Audi	Allroad Quattro	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C3	-	-	-	21"
1994	1998	Audi	Cabriolet	-	Front		Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1991	Audi	Coupe	Quattro	Front		Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1985	1987	Audi	Coupe	-	Front		Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1981	1984	Audi	Coupe	-	Front & Rear		Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1973	1979	Audi	Fox	-	Front & Rear		Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2015	2018	Audi	Q3	-	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2015	2018	Audi	Q3	-	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2009	2016	Audi	Q5	Inc. Hybrid	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
2009	2016	Audi	Q5	Inc. Hybrid	Passenger Side	Beam	Narrow PTB	97050	B	-		-	-	-	20"
2016	2018	Audi	Q7	-	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2016	2018	Audi	Q7	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2007	2015	Audi	Q7	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2007	2015	Audi	Q7	-	Passenger Side	Beam	I&L	97065	A	-	-	-	-	-	26"
1984	1986	Audi	Quattro	-	Front		Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1984	1986	Audi	Quattro	-	Rear		Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1983	1983	Audi	Quattro	-	Front & Rear		Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2016	Audi	RS5	Coupe & Cabriolet	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2012	2016	Audi	RS5	Coupe & Cabriolet	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2014	2016	Audi	RS7	-	Driver side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2014	2016	Audi	RS7	-	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2015	2016	Audi	S3	-	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2015	2016	Audi	S3	-	Passenger Side	Beam	Narrow PTB	97048	B	-	-	-	-	-	19"
2009	2016	Audi	S4	Sedan & Avant	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2009	2016	Audi	S4	Sedan & Avant	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2000	2002	Audi	S4	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2000	2002	Audi	S4	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2002	Audi	S4	-	Rear		Hook slot 9x3/9x4	97038	V	95038	C1	96138	Locking Clip	-	15"
1992	1994	Audi	S4	-	Front		Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2008	2016	Audi	S5	Coupe & Cabriolet	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2008	2016	Audi	S5	Coupe & Cabriolet	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2013	2016	Audi	S6	-	Driver side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2013	2016	Audi	S6	-	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2002	2003	Audi	S6	-	Rear		Hook slot 9x3/9x4	97038	V	95038	C1	96138	Locking Clip	-	15"
1998	2001	Audi	S6	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1998	2001	Audi	S6	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1997	Audi	S6	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1997	Audi	S6	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2012	2016	Audi	S7	-	Driver side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2012	2016	Audi	S7	-	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2012	2016	Audi	S8	-	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2012	2016	Audi	S8	-	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2014	2016	Audi	SQ5	-	Driver side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2014	2016	Audi	SQ5	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
1970	1972	Audi	Super 90	Inc. Wagon	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2015	2016	Audi	TT / TTS	Coupe & Roadster	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2015	2016	Audi	TT / TTS	Coupe & Roadster	Passenger Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2008	2014	Audi	TT / TTS	Coupe & Roadster	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2008	2014	Audi	TT / TTS	Coupe & Roadster	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2004	2007	Audi	TT	Coupe & Roadster	Front	Beam	Pin & Hook	97053	B	-	-	-	-	-	21"
1999	2003	Audi	TT	Coupe & Roadster	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1999	2003	Audi	TT	Coupe & Roadster	Passenger Side	Conv	Hook slot 9x4	97050	V	95050	C3	-	-	-	20"
1993	1994	Audi	V8 Quattro	-	Front	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1990	1992	Audi	V8 Quattro	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2008	2013	BMW	1 Series	M1, 118i, 120i, 125i, 128i, 130i, 135i	Front	Beam	I&L	97050	A	-	-	-	-	-	20"
2014	2016	BMW	2 Series	220i, 228i, 235i	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2014	2016	BMW	2 Series	220i. 228i. 235i	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
1975	1976	BMW	3	Si	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2012	2016	BMW	3 Series - F30 / F31 / F34 (Sedan / Wagon / Hatchback)	320i, 328d, 328i, 328i GT, 335i, 335i GT (incl. xDrive)	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2012	2016	BMW	3 Series - F30 / F31 / F34 (Sedan / Wagon / Hatchback)	320i, 328d, 328i, 328i GT, 335i, 335i GT (incl. xDrive)	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2012	2013	BMW	3 Series - F30 (Coupe / Convertible)	328i, 335i (incl. xDrive)	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2012	2013	BMW	3 Series - F30 (Coupe / Convertible)	328i, 335i (incl. xDrive)	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2010	2011	BMW	3 Series - E90 / E91 (Sedan / Wagon)	323i, 328i, 335d, 335i, (incl. xDrive)	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2010	2011	BMW	3 Series - E90 / E91 (Sedan / Wagon)	323i. 328i. 335d. 335i. (incl. xDrive)	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2006	2009	BMW	3 Series - E90 / E91 (Sedan / Wagon)	323i, 328i, 335d, 335i, (incl. xDrive)	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2006	2009	BMW	3 Series - E90 / E91 (Sedan / Wagon)	323i, 328i, 335d, 335i, (incl. xDrive)	Passenger Side	Beam	Pin & Hook	97048	B	-	-	-	-	-	19"
2010	2011	BMW	3 Series - E92 (Coupe)	328i, 335i, 335is (incl. xDrive)	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2010	2011	BMW	3 Series - E92 (Coupe)	328i. 335i. 335is (incl. xDrive)	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2010	2011	BMW	3 Series - E93 (Convertible)	328i, 335i, 335is (incl. xDrive)	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2010	2011	BMW	3 Series - E93 (Convertible)	328i, 335i, 335is (incl. xDrive)	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2011	2011	BMW	3 Series - E90 / E91 (Convertable / Coupe)	323i, 328i, 335d, 335i, (incl. xDrive)	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2011	2011	BMW	3 Series - E90 / E91 (Convertable / Coupe)	323i, 328i, 335d, 335i, (incl. xDrive)	Passenger Side	Beam	Pin & Hook	97043	B	-	-	-	-	-	17"
2007	2009	BMW	3 Series - E92 (Coupe)	Coupe (E92)	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2007	2009	BMW	3 Series - E92 (Coupe)	Coupe (E92)	Passenger Side	Beam	Pin & Hook	97045	B	-	-	-	-	-	18"
2007	2009	BMW	3 Series - E93 (Convertible)	Convertible (E93)	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2007	2009	BMW	3 Series - E93 (Convertible)	Convertible (E93)	Passenger Side	Beam	Pin & Hook	97045	B	-	-	-	-	-	18"
1999	2005	BMW	3 Series - E46 (Coupe / Convertible / Sedan)	320i, 323Ci, 323i, 325Ci, 325i, 325xi, 328Ci, 328i, 330Ci, 330i, 330xi	Driver Side	Conv	Hook slot 9x4 special	97055	V	-	-	-	-	-	22"
1999	2005	BMW	3 Series - E46 (Coupe / Convertible / Sedan)	320i, 323Ci, 323i, 325Ci, 325i, 325xi, 328Ci, 328i, 330Ci, 330i, 330xi	Passenger Side	Conv	Hook slot 9x4 special	97050	V	-	-	-	-	-	20"
1992	1998	BMW	3 Series - E36 (Sedan)	318i, 320i, 325i, 328i	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1998	BMW	3 Series - E36 (Sedan)	318i, 320i, 325i, 328i	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1998	BMW	3 Series - E36 (Convertible)	318i, 323i 328i	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1996	1998	BMW	3 Series - E36 (Convertible)	318i, 323i 328i	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	1995	BMW	3 Series - E36 (Convertible)	318i, 325i	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1995	BMW	3 Series - E36 (Convertible)	318i, 325i	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	1998	BMW	3 Series - E36 (Coupe)	318is, 323is	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1998	BMW	3 Series - E36 (Coupe)	318is, 323is	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1999	BMW	3 Series - E36 (Hatchback)	318ti	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1996	1998	BMW	3 Series - E36 (Hatchback)	318ti	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1996	BMW	3 Series - E36 (Hatchback)	318ti	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1996	BMW	3 Series - E36 (Hatchback)	318ti	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1987	1991	BMW	3 Series	318i,325,325e, 325es, 325i, 325is, 325ix	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1984	1985	BMW	3 Series	318i, 325e	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1980	1983	BMW	3 Series	320i	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2014	2016	BMW	4 Series (428i , 435i)	incl. Gran Coupe / xDrive	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2014	2016	BMW	4 Series (428i , 435i)	incl. Gran Coupe / xDrive	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2011	2016	BMW	5 Series - F10/F11 (Sedan / Hatchback)	528i. 535d. 535i. 550i (incl. xDrive)	Driver Side	Beam	Narrow Pin & Hook	97065	A	-	-	-	-	-	26"
2011	2016	BMW	5 Series - F10/F11 (Sedan / Hatchback)	528i, 535d, 535i, 550i (incl. xDrive)	Passenger Side	Beam	Narrow Pin & Hook	97045	A	-	-	-	-	-	18"
2004	2010	BMW	5 Series - E60	525i, 525xi, 528i, 528xi, 530i, 530xi, 535i, 535xi, 545i, 550i	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2004	2010	BMW	5 Series - E60	525i, 525xi, 528i, 528xi, 530i, 530xi, 535i, 535xi. 545i. 550i	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
1989	1995	BMW	5 Series - E34	525i, 525iT, 530i, 535i, 540i	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1989	1995	BMW	5 Series - E34	525i, 525iT, 530i, 535i, 540i	Passenger Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1982	1988	BMW	5 Series - E28	524td, 528e, 533i, 535i, 535is	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2011	2016	BMW	6 Series	F12/F13	Driver Side	Beam	Narrow Pin & Hook	97065	A	-	-	-	-	-	26"
2011	2016	BMW	6 Series	F12/F13	Passenger Side	Beam	Narrow Pin & Hook	97043	A	-	-	-	-	-	17"
2004	2010	BMW	6 Series - E63	645Ci, 650Ci, 650i	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2004	2010	BMW	6 Series - E63	645Ci. 650Ci. 650i	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
1985	1989	BMW	635CSi - E24	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1980	1984	BMW	633CSi	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	BMW	7 Series	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2016	2018	BMW	7 Series	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2009	2015	BMW	7 Series	-	Driver Side	Beam	Narrow Pin & Hook	97065	A	-	-	-	-	-	26"
2009	2015	BMW	7 Series	-	Passenger Side	Beam	Narrow Pin & Hook	97048	A	-	-	-	-	-	19"
1980	1984	BMW	733i	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1992	BMW	735i	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	1992	BMW	735i	-	Passenger Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1988	1990	BMW	735i	-	Front	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1985	1987	BMW	735i	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1992	BMW	735iL	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	1992	BMW	735iL	-	Passenger Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1988	1990	BMW	735iL	-	Front	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1993	2001	BMW	740i	-	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1993	2001	BMW	740i	-	Passenger Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1993	2001	BMW	740iL	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1993	2001	BMW	740iL	-	Passenger Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1991	2001	BMW	750iL	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	2001	BMW	750iL	-	Passenger Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1988	1990	BMW	750iL	-	Front	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2014	2016	BMW	i3	-	Driver Side	Beam	Pin & Hook	97070	B	-	-	-	-	-	28"
2014	2016	BMW	i3	-	Passenger Side	Beam	Pin & Hook	97053	B	-	-	-	-	-	21"
2015	2016	BMW	i8	-	Driver Side	Beam	Pin & Hook	97070	B	-	-	-	-	-	28"
2015	2016	BMW	i8	-	Passenger Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2016	2018	BMW	M2	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2016	2018	BMW	M2	-	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2015	2016	BMW	M3	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2015	2016	BMW	M3	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2012	2013	BMW	M3	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2012	2013	BMW	M3	-	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2010	2011	BMW	M3 - E90 (Sedan)	Sedan (E90)	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2010	2011	BMW	M3 - E90 (Sedan)	Sedan (E90)	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2010	2011	BMW	M3 - E92/93 (Coupe / Convertible)	Coupe / Convertible (E92/E93)	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2010	2011	BMW	M3 - E92/93 (Coupe / Convertible)	Coupe / Convertible (E92/E93)	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2008	2009	BMW	M3 - E90 (Sedan)	Sedan (E90)	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2008	2009	BMW	M3 - E90 (Sedan)	Sedan (E90)	Passenger Side	Beam	Pin & Hook	97048	B	-	-	-	-	-	19"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
2007	2009	BMW	M3 - E92/93 (Coupe / Convertible)	Coupe / Convertible (E92)	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2007	2009	BMW	M3 - E92/93 (Coupe / Convertible)	Coupe / Convertible (E92)	Passenger Side	Beam	Pin & Hook	97045	B	-	-	-	-	-	18"
1994	1999	BMW	M3 - E36	Inc. Convertible (E36)	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1994	1999	BMW	M3 - E36	Inc. Convertible (E36)	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1991	BMW	M3 - E30	Inc. Convertible (E30)	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2015	2015	BMW	M4	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2015	2015	BMW	M4	-	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2013	2015	BMW	M5 - F10	-	Driver Side	Beam	Narrow Pin & Hook	97065	A	-	-	-	-	-	26"
2013	2015	BMW	M5 - F10	-	Passenger Side	Beam	Narrow Pin & Hook	97045	A	-	-	-	-	-	18"
2013	2015	BMW	M6	Grand Coupe	Driver Side	Beam	Narrow Pin & Hook	97065	A	-	-	-	-	-	26"
2013	2015	BMW	M6	Grand Coupe	Passenger Side	Beam	Narrow Pin & Hook	97043	A	-	-	-	-	-	17"
2006	2010	BMW	M6	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2006	2010	BMW	M6	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
1987	1988	BMW	M6	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	BMW	X1	-	Driver Side	Beam	Narrow PTB	97065	B	-	-	-	-	-	26"
2016	2018	BMW	X1	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	16"
2012	2015	BMW	X1	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2012	2015	BMW	X1	-	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2011	2016	BMW	X3	F25	Driver Side	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2011	2016	BMW	X3	F25	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2004	2010	BMW	X3	E83	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2004	2010	BMW	X3	E83	Passenger Side	Conv	Hook slot 9x4	97050	V	95050	C3	-	-	-	20"
2015	2016	BMW	X4	-	Driver Side	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2015	2016	BMW	X4	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2014	2016	BMW	X5	-	Driver Side	Hybrid	Hook	97060	V	-	-	-	-	-	24"
2014	2016	BMW	X5	-	Passenger Side	Hybrid	Hook	97050	V	-	-	-	-	-	20"
2012	2013	BMW	X5	E70	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2012	2013	BMW	X5	E70	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2007	2011	BMW	X5	E70	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2007	2011	BMW	X5	E70	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2000	2006	BMW	X5	E53	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2000	2006	BMW	X5	E53	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2000	2006	BMW	X5	E53	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2015	2016	BMW	X6	E71	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2015	2016	BMW	X6	E71	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2012	2014	BMW	X6	E71	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2012	2014	BMW	X6	E71	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2008	2011	BMW	X6	E71	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2008	2011	BMW	X6	E71	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
1996	2002	BMW	Z3	E36	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C3	-	-	-	20"
2009	2015	BMW	Z4	E89	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2009	2015	BMW	Z4	E89	Passenger Side	Conv	Hook slot 9x4	97050	V	95050	C3	-	-	-	20"
2003	2008	BMW	Z4	E85	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
2003	2008	BMW	Z4	E85	Passenger Side	Conv	Hook slot 9x4	97050	V	95050	C3	-	-	-	20"
2018	2016	BMW	X1	-	Rear	Beam	Narrow PTB	97050	B	-	-	-	-	-	16"
2010	2010	Buick	Allure	Canada	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2010	Buick	Allure	Canada	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2006	2009	Buick	Allure	Canada	Front	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2005	Buick	Allure	Canada	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1973	1975	Buick	Apollo	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2017	2016	Buick	Cascada	Convertible	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
1971	1973	Buick	Centurion	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1997	2005	Buick	Century	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1984	1996	Buick	Century	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1991	Buick	Century	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1978	1981	Buick	Century	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Buick	Century	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1985	1990	Buick	Electra	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1968	1984	Buick	Electra	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2008	2016	Buick	Enclave	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2008	2016	Buick	Enclave	-	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2013	2016	Buick	Encore	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2013	2016	Buick	Encore	-	Passenger Side	Beam	PTB	97035	A	-	-	-	-	-	14"
2017	2016	Buick	Cascada	Convertible	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
2018	2016	Buick	Envision	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2018	2016	Buick	Envision	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1970	1990	Buick	Estate Wagon	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2010	2016	Buick	Lacrosse	-	Driver Side	Hybrid	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2010	2016	Buick	Lacrosse	-	Passenger Side	Hybrid	Hook slot 9x4	97045	V	95045	C3	-	-	-	18"
2006	2009	Buick	LaCrosse	-	Front	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2005	Buick	LaCrosse	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	2005	Buick	LeSabre	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1987	1991	Buick	LeSabre	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1970	1986	Buick	LeSabre	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2006	2011	Buick	Lucerne	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2006	2011	Buick	Lucerne	-	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
1991	2005	Buick	Park Avenue	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2007	Buick	Rainier	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2005	Buick	Rainier	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2005	Buick	Rainier	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1988	1991	Buick	Reatta	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
2011	2016	Buick	Regal	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2016	Buick	Regal	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	2004	Buick	Regal	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1988	1996	Buick	Regal	-	Front	Conv	Pin Arm 1/4"	97050	V	-	-	-	-	-	20"
1978	1987	Buick	Regal	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Buick	Regal	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2002	2007	Buick	Rendezvous	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2002	2007	Buick	Rendezvous	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2002	2007	Buick	Rendezvous	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	1999	Buick	Riviera	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1986	1993	Buick	Riviera	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1971	1985	Buick	Riviera	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1991	1996	Buick	Roadmaster	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1991	1996	Buick	Roadmaster	-	Rear	Conv	Pin Arm	97043	V	-	-	-	-	-	17"
1983	1989	Buick	Skyhawk	-	Front & Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1986	1998	Buick	Skylark	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1980	1985	Buick	Skylark	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1968	1979	Buick	Skylark	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1985	1987	Buick	Somerset	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1968	1969	Buick	Special	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1968	1972	Buick	Sportwagon	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2005	2007	Buick	Terraza	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2005	2007	Buick	Terraza	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2005	2007	Buick	Terraza	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2018	2017	Buick	LaCrosse	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2018	2017	Buick	Lacrosse	-	Driver Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2016	Buick	Verano	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2016	2016	Buick	Verano	-	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2012	2015	Buick	Verano	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2012	2015	Buick	Verano	-	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
1968	1970	Buick	Wildcat	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1993	Cadillac	Allante	-	Front	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
2016	2018	Cadillac	ATS	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2018	Cadillac	ATS	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1987	1992	Cadillac	Brougham	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1976	Cadillac	Calais	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1997	2001	Cadillac	Catera	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C2	-	-	-	24"
1997	2001	Cadillac	Catera	-	Passenger Side	Conv	Hook slot 9x4	97048	V	95048	C3	-	-	-	19"
1982	1988	Cadillac	Cimarron	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2014	2018	Cadillac	CTS	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2014	2018	Cadillac	CTS	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
2011	2013	Cadillac	CTS	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2013	Cadillac	CTS	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2008	2010	Cadillac	CTS	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2010	Cadillac	CTS	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2003	2007	Cadillac	CTS	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2007	Cadillac	CTS	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2016	2018	Cadillac	CTS-V	Coupe	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2016	2018	Cadillac	CTS-V	Coupe	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
2009	2014	Cadillac	CTS-V	Coupe & Wagon	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2014	Cadillac	CTS-V	Coupe & Wagon	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2016	2018	Cadillac	CT6	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2016	2018	Cadillac	CT6	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2006	2011	Cadillac	DTS	-	Front	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2005	Cadillac	DeVille	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	1999	Cadillac	DeVille	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1985	1990	Cadillac	DeVille	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1970	1984	Cadillac	DeVille	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2014	2016	Cadillac	ELR	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2014	2016	Cadillac	ELR	-	Passenger Side	Beam	PTB	97065	A	-	-	-	-	-	26"
1992	2002	Cadillac	Eldorado	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1986	1991	Cadillac	Eldorado	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1970	1985	Cadillac	Eldorado	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2015	2018	Cadillac	Escalade	-	Front	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2014	Cadillac	Escalade	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2007	Cadillac	Escalade	-	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2002	2006	Cadillac	Escalade	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2006	Cadillac	Escalade	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1999	2000	Cadillac	Escalade	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
2016	2018	Cadillac	Escalade	ESV	Front	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2012	Cadillac	Escalade	ESV	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2007	Cadillac	Escalade	ESV	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2005	2006	Cadillac	Escalade	ESV	Front	Conv	Hook	97055	V	-	-	-	-	-	22"
2005	2006	Cadillac	Escalade	ESV	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2003	2004	Cadillac	Escalade	ESV	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2004	Cadillac	Escalade	ESV	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2008	2013	Cadillac	Escalade	EXT	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2007	Cadillac	Escalade	EXT	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2005	2006	Cadillac	Escalade	EXT	Front	Conv	Hook	97055	V	-	-	-	-	-	22"
2002	2004	Cadillac	Escalade	EXT	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	1996	Cadillac	Fleetwood	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1989	1990	Cadillac	Fleetwood	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1985	1988	Cadillac	Fleetwood	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1968	1985	Cadillac	Fleetwood	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1998	2004	Cadillac	Seville	SLS / STS	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1998	2004	Cadillac	Seville	SLS / STS	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1997	Cadillac	Seville	SLS / STS	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1986	1991	Cadillac	Seville	SLS / STS	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1976	1985	Cadillac	Seville	SLS / STS	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1993	1993	Cadillac	Sixty/60 Special	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
2010	2015	Cadillac	SRX	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2010	2015	Cadillac	SRX	-	Passenger Side	Beam	PTB	97043	A	-	-	-	-	-	17"
2004	2009	Cadillac	SRX	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2009	Cadillac	SRX	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2005	2010	Cadillac	STS	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2005	2010	Cadillac	STS	-	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2004	2009	Cadillac	XLR	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2004	2009	Cadillac	XLR	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2018	Cadillac	XTS	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2018	Cadillac	XTS	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2017	2018	Cadillac	XT5	Crossover	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2017	2018	Cadillac	XT5	Crossover	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1985	2005	Chevrolet	Astro	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2008	2013	Chevrolet	Avalanche	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2007	Chevrolet	Avalanche	-	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2002	2006	Chevrolet	Avalanche 1500 / 2500	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2011	Chevrolet	Aveo	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2011	Chevrolet	Aveo	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2008	Chevrolet	Aveo	Sedan	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2008	Chevrolet	Aveo	Sedan	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2007	Chevrolet	Aveo	Hatchback	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2007	Chevrolet	Aveo	Hatchback	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2007	2007	Chevrolet	Aveo	Hatchback	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2004	2006	Chevrolet	Aveo	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2006	Chevrolet	Aveo	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2004	2006	Chevrolet	Aveo	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2009	2011	Chevrolet	Aveo 5	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2011	Chevrolet	Aveo 5	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2011	Chevrolet	Aveo 5	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2006	2008	Chevrolet	Aveo 5	-	Driver Side	Conv	Hook	97055	V	-	-	-	-	-	22"
2006	2008	Chevrolet	Aveo 5	-	Passenger Side	Conv	Hook	97048	V	-	-	-	-	-	19"
2006	2008	Chevrolet	Aveo 5	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1981	1981	Chevrolet	Belair	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1975	Chevrolet	Belair	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1996	Chevrolet	Beretta	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1971	1972	Chevrolet	Biscayne	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1968	1970	Chevrolet	Biscayne	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1993	1994	Chevrolet	Blazer	Full Size C/K	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1992	Chevrolet	Blazer	Full Size C/K	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1995	2005	Chevrolet	Blazer	S-Series	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1983	1994	Chevrolet	Blazer	Compact S-10	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2016	2018	Chevrolet	Volt	EV	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2016	2018	Chevrolet	Volt	EV	Passenger Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2010	2015	Chevrolet	Camaro	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2015	Chevrolet	Camaro	-	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1998	2002	Chevrolet	Camaro	-	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1982	1992	Chevrolet	Camaro	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1982	1988	Chevrolet	Camaro	-	Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1977	1981	Chevrolet	Camaro	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1976	Chevrolet	Camaro	(w/ Double Arm)	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1976	Chevrolet	Camaro	(w/ Single Arm)	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1991	1996	Chevrolet	Caprice	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1990	1996	Chevrolet	Caprice	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1971	1990	Chevrolet	Caprice	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1995	2005	Chevrolet	Cavalier	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	2005	Chevrolet	Cavalier	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1990	1994	Chevrolet	Cavalier	-	Front	Conv	Pin Arm	97043	V	-	-	-	-	-	17"
1982	1989	Chevrolet	Cavalier	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1988	Chevrolet	Cavalier	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1984	1990	Chevrolet	Celebrity	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1989	Chevrolet	Celebrity	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1968	1973	Chevrolet	Chevelle	Inc.Wagon (w/ Double & SingleArm)	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1987	Chevrolet	Chevette	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1987	Chevrolet	Chevette	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1976	1981	Chevrolet	Chevette	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1980	1985	Chevrolet	Citation / Citation II	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2004	2005	Chevrolet	Classic	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2005	Chevrolet	Classic	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2010	Chevrolet	Cobalt	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2010	Chevrolet	Cobalt	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2015	2018	Chevrolet	Colorado	-	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2015	2018	Chevrolet	Colorado	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
2004	2012	Chevrolet	Colorado	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2012	Chevrolet	Colorado	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1987	1996	Chevrolet	Corsica	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
2014	2018	Chevrolet	Corvette	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	Chevrolet	Corvette	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2013	Chevrolet	Corvette	C6	Front	Conv	Hook	97053	V	-	-	-	-	-	21"
1997	2004	Chevrolet	Corvette	C5	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1984	1996	Chevrolet	Corvette	-	Front	Conv	Pin Arm	97050	V	-	-	-	-	-	20"
1968	1982	Chevrolet	Corvette	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2016	2018	Chevrolet	Cruze	-	Driver Side	Beam	PTB	97070	A	-	-	-	-	-	28"
2016	2018	Chevrolet	Cruze	-	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2011	2015	Chevrolet	Cruze	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2015	Chevrolet	Cruze	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1978	1987	Chevrolet	El Camino	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1968	1977	Chevrolet	El Camino	(w/ Single Arm) Pickup	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1968	1972	Chevrolet	El Camino	(w/ Double Arm) Pickup	Driver Side	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2004	2006	Chevrolet	Epica	Canada	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2006	Chevrolet	Epica	Canada	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2010	2018	Chevrolet	Equinox	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2010	2018	Chevrolet	Equinox	-	Passenger Side	Beam	I&L	97043	A	-	-	-	-	-	17"
2005	2009	Chevrolet	Equinox	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2009	Chevrolet	Equinox	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2009	Chevrolet	Equinox	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1996	2015	Chevrolet	Express	1500 / 2500 / 3500 / 4500 / Pasajeros	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2011	Chevrolet	HHR	-	Front	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2014	2018	Chevrolet	Impala	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2014	2018	Chevrolet	Impala	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2013	Chevrolet	Impala	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2013	Chevrolet	Impala	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2006	2010	Chevrolet	Impala	-	Front	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2005	Chevrolet	Impala	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	1996	Chevrolet	Impala	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1971	1985	Chevrolet	Impala	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2005	2008	Chevrolet	Kodiak	C4500 / C5500 / C6500 / C7500 Kodiak	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1973	1976	Chevrolet	Laguna	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1995	2001	Chevrolet	Lumina	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1994	Chevrolet	Lumina	-	Front	Conv	Pin Arm 1/4"	97050	V	-	-	-	-	-	20"
1990	1996	Chevrolet	Lumina APV / Lumina Van	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
2016	2018	Chevrolet	Malibu	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Chevrolet	Malibu	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2013	2015	Chevrolet	Malibu	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2013	2015	Chevrolet	Malibu	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2008	2012	Chevrolet	Malibu	excluding Classic for 2008	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2008	2012	Chevrolet	Malibu	excluding Classic for 2008	Passenger Side	Beam	PTB	97053	A	-	-	-	-	-	21"
2008	2008	Chevrolet	Malibu (Classic)	Classic LS / LT	Driver Side	Conv	Hook	97055	V	-	-	-	-	-	22"
2008	2008	Chevrolet	Malibu (Classic)	Classic LS / LT	Passenger Side	Conv	Hook	97050	V	-	-	-	-	-	20"
2004	2007	Chevrolet	Malibu	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2007	Chevrolet	Malibu	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	2003	Chevrolet	Malibu	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	2003	Chevrolet	Malibu	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1978	1983	Chevrolet	Malibu	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Chevrolet	Malibu	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2004	2007	Chevrolet	Malibu Maxx	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2007	Chevrolet	Malibu Maxx	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	2001	Chevrolet	Metro	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	2001	Chevrolet	Metro	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1992	Chevrolet	Metro	-	Driver Side	Conv	Hook	97050	V	-	-	-	-	-	20"

PIAA

YEAR (Range)															
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
1992	1992	Chevrolet	Metro	-	Passenger Side	Conv	Hook	97045	V	-	-	-	-	-	18"
2006	2007	Chevrolet	Monte Carlo	-	Front	Hybrid	Hook	97055	V	-	-	-	-	-	22"
1995	2005	Chevrolet	Monte Carlo	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1978	1988	Chevrolet	Monte Carlo	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Chevrolet	Monte Carlo	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1970	1972	Chevrolet	Monte Carlo	(w/ Double Arm)	Driver Side	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1969	1979	Chevrolet	Nova	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2004	2007	Chevrolet	Optra	Canada	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2007	Chevrolet	Optra	Canada	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2007	Chevrolet	Optra	Hatchback	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2002	Chevrolet	Pickup (C/K Series)	C/K 3500	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	2000	Chevrolet	Pickup (C/K Series)	C/K 1500, 2500,3500 (Exc.Avalanche,Silverado)	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1988	1994	Chevrolet	Pickup (C/K Series)	C/K 1500, 2500,3500 (Exc.Avalanche,Silverado)	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1988	1991	Chevrolet	Pickup (R/V Series)	25003500	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1987	Chevrolet	Pickup (R/V Series)	10,20,30	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1994	2004	Chevrolet	Pickup (S-10)	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1982	1993	Chevrolet	Pickup (S-10)	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1998	2002	Chevrolet	Prizm	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	2002	Chevrolet	Prizm	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2014	2018	Chevrolet	Silverado	1500. 2500 2500HD. 3500 HD	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2008	2013	Chevrolet	Silverado	-	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2007	2007	Chevrolet	Silverado	1500, 1500HD, 2500, 2500HD, 3500, 3500HD	Front	Conv	Hook	97055	V	-	-	-	-	-	22"
2005	2006	Chevrolet	Silverado	1500, 1500HD, 2500, 2500HD, 3500	Front	Conv	Hook	97055	V	-	-	-	-	-	22"
1999	2004	Chevrolet	Silverado	Silverado. 1500, 2500	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	Chevrolet	Silverado	1500. 2500 2500HD. 3500 HD	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2012	2018	Chevrolet	Sonic	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2012	2018	Chevrolet	Sonic	-	Passenger Side	Beam	I&L	97038	A	-	-	-	-	-	15"
2016	2018	Chevrolet	Spark	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Chevrolet	Spark	-	Passenger Side	Conv	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2012	2015	Chevrolet	Spark	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2012	2015	Chevrolet	Spark	-	Passenger Side	Beam	PTB	97040	A	-	-	-	-	-	16"
1988	1988	Chevrolet	Spectrum	Canada	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1992	Chevrolet	Sprint	Canada	Driver Side	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1989	1992	Chevrolet	Sprint	Canada	Passenger Side	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2014	2015	Chevrolet	SS	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2014	2015	Chevrolet	SS	-	Passenger Side	Beam	I&L	97038	A	-	-	-	-	-	15"
2003	2006	Chevrolet	SSR	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2006	Chevrolet	SSR	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2015	2018	Chevrolet	Suburban	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2014	Chevrolet	Suburban	including 1500 / 2500 (late 2008)	Front	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2008	Chevrolet	Suburban	early 2008	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2007	2007	Chevrolet	Suburban	1500/2500	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2000	2006	Chevrolet	Suburban	1500/2500	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2006	Chevrolet	Suburban	1500/2500	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	1999	Chevrolet	Suburban	C1500.C2500. K1500. K2500. 1500	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1994	Chevrolet	Suburban	C1500,C2500, K1500, K2500	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1991	Chevrolet	Suburban	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2015	2018	Chevrolet	Suburban	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	Chevrolet	Tahoe	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	Chevrolet	Tahoe	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2013	Chevrolet	Tahoe	(late 2008)	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2008	Chevrolet	Tahoe	(early 2008)	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2000	2006	Chevrolet	Tahoe	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2006	Chevrolet	Tahoe	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	1999	Chevrolet	Tahoe	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1999	2004	Chevrolet	Tracker	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2004	Chevrolet	Tracker	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1998	1998	Chevrolet	Tracker	-	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1998	1998	Chevrolet	Tracker	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2007	2009	Chevrolet	Trailblazer	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2006	Chevrolet	Trailblazer	incl. EXT	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2006	Chevrolet	Trailblazer	incl. EXT	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2012	2018	Chevrolet	Traverse	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2012	2018	Chevrolet	Traverse	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2009	2011	Chevrolet	Traverse	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2009	2011	Chevrolet	Traverse	-	Passenger Side	Beam	PTB	97053	A	-	-	-	-	-	21"
2015	2018	Chevrolet	Trax	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2015	2018	Chevrolet	Trax	-	Passenger Side	Beam	PTB	97035	A	-	-	-	-	-	14"
2005	2008	Chevrolet	Uplander	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2005	2008	Chevrolet	Uplander	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2005	2008	Chevrolet	Uplander	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2001	2002	Chevrolet	Van (G-Series)	G30	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1996	1996	Chevrolet	Van (G-Series)	G30	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1993	1995	Chevrolet	Van (G-Series)	G10, G20, G30	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1983	1992	Chevrolet	Van (G-Series)	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1991	1999	Chevrolet	Van (P-Series)	-	Front	Conv	Hook	97045	V	-	-	-	-	-	18"
1997	2005	Chevrolet	Venture	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	2005	Chevrolet	Venture	-	Passenger Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	2005	Chevrolet	Venture	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1993	1996	Chevrolet	Venture	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1983	1992	Chevrolet	Venture	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2011	2018	Chevrolet	Volt	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2011	2018	Chevrolet	Volt	-	Passenger Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2005	2008	Chevrolet	W-Series Tiltmaster	W3500 . W4500. W5500 . W5500HD	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2015	2016	Chrysler	200	-	Driver Side	Beam	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2015	2016	Chrysler	200	-	Passenger Side	Beam	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2014	Chrysler	200	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2014	Chrysler	200	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2018	Chrysler	300 - 300C	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2018	Chrysler	300 - 300C	-	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2005	2010	Chrysler	300 - 300C	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1970	1971	Chrysler	300	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1999	2004	Chrysler	300M	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2004	Chrysler	300M	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2009	Chrysler	Aspen	-	Driver Side	Conv	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2007	2009	Chrysler	Aspen	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	-	-	-	21"
1995	2000	Chrysler	Cirrus	-	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1995	2000	Chrysler	Cirrus	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2008	2008	Chrysler	Cirrus Sedan	(MEX)	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2008	2008	Chrysler	Cirrus Sedan	(MEX)	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2008	2008	Chrysler	Cirrus Convertible	(MEX)	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2008	2008	Chrysler	Cirrus Convertible	(MEX)	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1997	2004	Chrysler	Concorde	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	2004	Chrysler	Concorde	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1996	Chrysler	Concorde	(w/o washer nozzle)	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1993	1994	Chrysler	Concorde	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1993	1994	Chrysler	Concorde	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1975	1983	Chrysler	Cordoba	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2003	2008	Chrysler	Crossfire	Coupe & Roadster	Driver Side	Conv	Hook slot 9x4	97050	V	95050	C3	-	-	-	20"
2003	2008	Chrysler	Crossfire	Coupe & Roadster	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1984	1993	Chrysler	Daytona Canada	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1988	1993	Chrysler	Dynasty Canada	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1983	1984	Chrysler	E Class	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1983	1993	Chrysler	Fifth Avenue	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1974	1993	Chrysler	Imperial	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1969	1973	Chrysler	Imperial	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1993	2004	Chrysler	Intrepid Canada	(w/oWasher)	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1993	2004	Chrysler	Intrepid Canada	(w/oWasher)	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1984	1986	Chrysler	Laser	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1994	1995	Chrysler	LeBaron	Convertible	Front	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
1989	1993	Chrysler	LeBaron	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1988	Chrysler	LeBaron	Coupe & Convertible	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1988	Chrysler	LeBaron	Sedan	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1985	1989	Chrysler	LeBaron	GTS	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1982	1986	Chrysler	LeBaron	Exc.GTS	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1980	1981	Chrysler	LeBaron	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1980	1981	Chrysler	LeBaron	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1977	1979	Chrysler	LeBaron	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1997	2001	Chrysler	LHS	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	2001	Chrysler	LHS	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1996	Chrysler	LHS	(w/o washer nozzle)	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	1994	Chrysler	LHS	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	1994	Chrysler	LHS	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2003	Chrysler	Neon Canada	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2003	Chrysler	Neon Canada	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1995	1996	Chrysler	New Yorker	-	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	1994	Chrysler	New Yorker	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	1994	Chrysler	New Yorker	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1988	1993	Chrysler	New Yorker	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1983	1987	Chrysler	New Yorker	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1974	1982	Chrysler	New Yorker	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1969	1973	Chrysler	New Yorker	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1974	1981	Chrysler	Newport	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1969	1973	Chrysler	Newport	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2008	2008	Chrysler	Nueva Town & Country	Mexico	Driver Side	Conv	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2008	2008	Chrysler	Nueva Town & Country	Mexico	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2017	2018	Chrysler	Pacifica	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"

PIAA

YEAR (Range)									SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2017	2018	Chrysler	Pacifica	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2004	2008	Chrysler	Pacifica	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2010	Chrysler	PT Cruiser	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2010	Chrysler	PT Cruiser	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2001	2010	Chrysler	PT Cruiser	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2003	2008	Chrysler	PT Cruiser Convertible	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2008	Chrysler	PT Cruiser Convertible	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2010	Chrysler	Sebring	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2007	2010	Chrysler	Sebring	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2006	2006	Chrysler	Sebring	-	Front	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2001	2005	Chrysler	Sebring	Convertible, Sedan	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2001	2005	Chrysler	Sebring	Convertible, Sedan	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2001	2005	Chrysler	Sebring	Coupe	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2001	2005	Chrysler	Sebring	Coupe	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	-	-	-	21"
1997	2000	Chrysler	Sebring	Convertible	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1997	2000	Chrysler	Sebring	Convertible	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1996	2000	Chrysler	Sebring	Coupe	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1996	2000	Chrysler	Sebring	Coupe	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1996	1996	Chrysler	Sebring	Convertible	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1996	1996	Chrysler	Sebring	Convertible	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1995	Chrysler	Sebring	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1995	1995	Chrysler	Sebring	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1989	1991	Chrysler	TC Maserati	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2008	2015	Chrysler	Town & Country	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2015	Chrysler	Town & Country	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2012	2015	Chrysler	Town & Country	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2001	2007	Chrysler	Town & Country	-	Driver Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2007	Chrysler	Town & Country	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2007	Chrysler	Town & Country	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1996	2000	Chrysler	Town & Country	-	Driver Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1996	2000	Chrysler	Town & Country	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1996	2000	Chrysler	Town & Country	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	1995	Chrysler	Town & Country	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1995	Chrysler	Town & Country	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1994	Chrysler	Town & Country	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	1994	Chrysler	Town & Country	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1994	Chrysler	Town & Country	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1993	Chrysler	Town & Country	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1991	1993	Chrysler	Town & Country	-	Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1990	1990	Chrysler	Town & Country	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1990	1990	Chrysler	Town & Country	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1981	1988	Chrysler	Town & Country	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2001	2008	Chrysler	Voyager	(MEX)	Driver Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2008	Chrysler	Voyager	(MEX)	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2008	Chrysler	Voyager	(MEX)	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2001	2003	Chrysler	Voyager	-	Driver Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2003	Chrysler	Voyager	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2003	Chrysler	Voyager	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2000	2000	Chrysler	Voyager	-	Driver Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2000	2000	Chrysler	Voyager	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2000	2000	Chrysler	Voyager	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1999	2002	Daewoo	Lanos	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2002	Daewoo	Lanos	-	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2002	Daewoo	Leganza	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2002	Daewoo	Leganza	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2002	Daewoo	Nubira	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2002	Daewoo	Nubira	Inc. Wagon	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1999	1999	Daewoo	Nubira	Hatchback	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1982	1988	Dodge	400, 600	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1981	1989	Dodge	Aries	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1976	1980	Dodge	Aspen	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2008	2014	Dodge	Avenger	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2008	2014	Dodge	Avenger	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1995	2000	Dodge	Avenger	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1995	2000	Dodge	Avenger	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2012	Dodge	Caliber	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2012	Dodge	Caliber	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2001	2007	Dodge	Caravan, Grand Caravan	-	Driver Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2007	Dodge	Caravan, Grand Caravan	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
2001	2007	Dodge	Caravan, Grand Caravan	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1996	2000	Dodge	Caravan, Grand Caravan	-	Driver Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1996	2000	Dodge	Caravan, Grand Caravan	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1996	2000	Dodge	Caravan, Grand Caravan	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	1995	Dodge	Caravan, Grand Caravan	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1995	Dodge	Caravan, Grand Caravan	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1994	Dodge	Caravan, Grand Caravan	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	1994	Dodge	Caravan, Grand Caravan	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1994	Dodge	Caravan, Grand Caravan	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1993	Dodge	Caravan, Grand Caravan	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1991	1993	Dodge	Caravan, Grand Caravan	-	Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1990	Dodge	Caravan, Grand Caravan	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1990	Dodge	Caravan, Grand Caravan	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2009	2018	Dodge	Challenger	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1970	1974	Dodge	Challenger	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2009	2018	Dodge	Challenger	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2018	Dodge	Charger	-	Driver Side	Hybrid	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2018	Dodge	Charger	-	Passenger Side	Hybrid	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2006	2010	Dodge	Charger	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2010	Dodge	Charger	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1975	1978	Dodge	Charger	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1974	Dodge	Charger	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1993	1995	Dodge	Colt	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1995	Dodge	Colt	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1992	Dodge	Colt	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1992	Dodge	Colt	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1975	1976	Dodge	Coronet	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1974	Dodge	Coronet	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2002	2010	Dodge	Dakota	-	Front	Conv	Hook slot 9x4	97053	V	95053	C4	-	-	-	21"
1997	2001	Dodge	Dakota	-	Front	Conv	Hook slot 9x4	97050	V	95050	C4	-	-	-	20"
1987	1996	Dodge	Dakota	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2013	2016	Dodge	Dart	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2016	Dodge	Dart	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1993	Dodge	Daytona	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1988	Dodge	Daytona	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1977	1989	Dodge	Diplomat	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1980	1981	Dodge	Diplomat	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2011	2018	Dodge	Durango	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2018	Dodge	Durango	-	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2008	2009	Dodge	Durango	-	Driver Side	Conv	Hook slot 9x4	97065	V	95065	C4	-	-	-	26"
2008	2009	Dodge	Durango	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	-	-	-	20"
2004	2007	Dodge	Durango	-	Driver Side	Conv	Hook slot 9x4	97065	V	95065	C4	-	-	-	26"
2004	2007	Dodge	Durango	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	-	-	-	21"
2002	2003	Dodge	Durango	-	Front	Conv	Hook slot 9x4	97053	V	95053	C4	-	-	-	21"
2002	2003	Dodge	Durango	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	-	-	-	16"
1998	2001	Dodge	Durango	-	Front	Conv	Hook slot 9x4	97050	V	95050	C4	-	-	-	20"
1998	2001	Dodge	Durango	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	-	-	-	16"
1988	1993	Dodge	Dynasty	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2008	2018	Dodge	Grand Caravan	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2018	Dodge	Grand Caravan	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2011	2018	Dodge	Grand Caravan	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1997	2004	Dodge	Intrepid	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	2004	Dodge	Intrepid	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1996	Dodge	Intrepid	(w/o washer nozzle)	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1993	1994	Dodge	Intrepid	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1993	1994	Dodge	Intrepid	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2018	Dodge	Journey	-	Driver Side	Beam	Hook slot 9x4	97060	V	95060	C4	-	-	-	24"
2009	2018	Dodge	Journey	-	Passenger Side	Beam	Hook slot 9x4	97048	V	95048	C4	-	-	-	19"
1985	1989	Dodge	Lancer	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2005	2008	Dodge	Magnum	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2008	Dodge	Magnum	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1978	1979	Dodge	Magnum XE	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1988	Dodge	Mini-Ram Van	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1988	Dodge	Mini-Ram Van	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1980	1983	Dodge	Mirada	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1990	1992	Dodge	Monaco	-	Front	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
1974	1978	Dodge	Monaco	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1969	1973	Dodge	Monaco	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2000	2005	Dodge	Neon	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2005	Dodge	Neon	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1995	1999	Dodge	Neon	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1999	Dodge	Neon	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2012	Dodge	Nitro	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1969	1973	Dodge	Polara	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2009	2013	Dodge	Ram 1500/2500/3500/4500/5500	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2008	Dodge	Ram 1500/2500/3500	-	Front	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	2001	Dodge	Ram 1500/2500/3500	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2003	Dodge	Ram Van	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1998	1998	Dodge	Ram Van	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	1997	Dodge	Ram Van	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1974	1993	Dodge	Ramcharger	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"

PIAA

YEAR (Range)									SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
1987	1994	Dodge	Shadow	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1989	1995	Dodge	Spirit	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2007	2010	Dodge	Sprinter	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2007	2010	Dodge	Sprinter	-	Passenger Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2003	2006	Dodge	Sprinter	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2003	2006	Dodge	Sprinter	-	Passenger Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1979	1981	Dodge	St. Regis	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1991	1996	Dodge	Stealth	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1991	1996	Dodge	Stealth	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	2006	Dodge	Stratus	-	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C2	-	-	-	22"
1995	2006	Dodge	Stratus	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C2	-	-	-	22"
2001	2005	Dodge	Stratus	Coupe	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C2	-	-	-	24"
2001	2005	Dodge	Stratus	Coupe	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	-	-	-	21"
2003	2005	Dodge	SX 2.0 / SRT-4 Canada	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2005	Dodge	SX 2.0 / SRT-4 Canada	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	2002	Dodge	Viper, GTS, R/T	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1988	1989	Eagle	Medallion	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1989	Eagle	Medallion	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1988	1992	Eagle	Premier	-	Front	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
1993	1996	Eagle	Summit	Coupe & Sedan	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1996	Eagle	Summit	Coupe & Sedan	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1996	Eagle	Summit	Wagon	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1996	Eagle	Summit	Wagon	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1996	Eagle	Summit	Wagon	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1991	1992	Eagle	Summit	Hatchback & Sedan	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1992	Eagle	Summit	Hatchback & Sedan	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1995	1998	Eagle	Talon	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1995	1998	Eagle	Talon	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	1998	Eagle	Talon	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	1996	Eagle	Talon	-	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1994	Eagle	Talon	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1997	Eagle	Vision	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1995	1997	Eagle	Vision	-	Passenger Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1993	1994	Eagle	Vision	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1993	1994	Eagle	Vision	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1988	1988	Eagle	Wagon	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1995	1995	Ferrari	348 Spider	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	2000	Ferrari	F355	Spider	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	2000	Ferrari	F355	Spider	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	1999	Ferrari	F355	F1Berlinetta	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1998	1999	Ferrari	F355	F1Berlinetta	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	1999	Ferrari	F355	GTS	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1997	1999	Ferrari	F355	GTS	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1995	Ferrari	F512M	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1985	1990	Ferrari	Mondial 3.2	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1985	1988	Ferrari	Testarossa	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2011	2016	Fiat	500	Inc. c. e	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2016	Fiat	500	Inc. c. e	Passenger Side	Hybrid	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2014	2018	Fiat	500L	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2014	2018	Fiat	500L	-	Passenger Side	Beam	PTB	97038	A	-	-	-	-	-	15"
2015	2018	Fiat	500X	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2015	2018	Fiat	500X	-	Passenger Side	Beam	PTB	97038	A	-	-	-	-	-	15"
1994	1997	Ford	Aerostar	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	1997	Ford	Aerostar	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1986	1993	Ford	Aerostar	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1986	1993	Ford	Aerostar	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1994	1998	Ford	Aspire	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1994	1998	Ford	Aspire	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	1996	Ford	Bronco	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1980	1994	Ford	Bronco	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1980	1990	Ford	Bronco II	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1995	2001	Ford	Contour	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	2001	Ford	Contour	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2012	2015	Ford	C-Max	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2012	2015	Ford	C-Max	-	Passenger Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2005	2007	Ford	Crown Victoria	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2004	Ford	Crown Victoria	-	Front	Conv	Pin Arm 1/4"	97055	V	-	-	-	-	-	22"
1993	2002	Ford	Crown Victoria	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1993	Ford	Crown Victoria	-	Front	Conv	Pin arm 1/4"	97055	V	-	-	-	-	-	22"
1983	1991	Ford	Crown Victoria	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1977	Ford	Custom	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1998	2014	Ford	E-Series (Econoline Van)	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1994	1997	Ford	E-Series (Econoline Van)	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1993	Ford	E-Series (Econoline Van)	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1981	1991	Ford	E-Series (Econoline Van)	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1975	1980	Ford	E-Series (Econoline Van)	-	Front	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
2013	2018	Ford	Edge	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2013	2018	Ford	Edge	-	Passenger Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2007	2014	Ford	Edge	-	Driver Side	Conv	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2007	2014	Ford	Edge	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C3	-	-	-	20"
1975	1976	Ford	Elite	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2008	2012	Ford	Escape	-	Front	Beam	I&L	97050	A	-	-	-	-	-	20"
2004	2007	Ford	Escape	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2004	2007	Ford	Escape	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2003	Ford	Escape	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1994	2002	Ford	Escort	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1994	2002	Ford	Escort	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1993	Ford	Escort	-	Driver Side	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
1991	1993	Ford	Escort	-	Passenger Side	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1981	1990	Ford	Escort	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1981	1990	Ford	Escort	HATCHBACK	Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2000	2005	Ford	Excursion	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2005	Ford	Excursion	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1982	1988	Ford	EXP	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2008	2018	Ford	Expedition	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2008	Ford	Expedition	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2003	2007	Ford	Expedition	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2007	Ford	Expedition	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1999	2002	Ford	Expedition	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2002	Ford	Expedition	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1997	1998	Ford	Expedition	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	1998	Ford	Expedition	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2008	2018	Ford	Expedition	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2018	Ford	Explorer	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2011	2018	Ford	Explorer	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2006	2010	Ford	Explorer	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2005	Ford	Explorer	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2005	Ford	Explorer	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2004	Ford	Explorer	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2004	Ford	Explorer	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1991	2001	Ford	Explorer	2/4-Door	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2000	2004	Ford	Explorer Sport	2-Door	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2010	Ford	Explorer Sport Trac	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2005	Ford	Explorer Sport Trac	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2018	Ford	F-150	-	Driver Side	Beam	Hook 9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2008	Ford	F-150	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	2008	Ford	F-150 / 250 (MEX)	(MEX)	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2009	2018	Ford	F-150	-	Passenger Side	Beam	Hook 9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2018	Ford	F-Series (Super Duty)	F-250/350/450/550	Driver Side	Beam	Hook 9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2008	Ford	F-Series (Super Duty)	F-250/350/450/550	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2008	2008	Ford	F-Series (Super Duty)	F-650/750	Front	Beam	Hook	97050	V	-	-	-	-	-	20"
2004	2007	Ford	F-Series (Super Duty)	F-250/350/450	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2003	Ford	F-Series (Pickup)	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	1998	Ford	F-Series (Pickup)	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	1997	Ford	F-Series (Pickup)	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1996	Ford	F-Series (Pickup)	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1980	1994	Ford	F-Series (Pickup)	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1970	Ford	Fairlane	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1978	1983	Ford	Fairmont	-	Front & Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1989	1993	Ford	Festiva	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2018	Ford	F-Series (Super Duty)	F-250/350/450/550	Passenger Side	Beam	Hook 9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2018	Ford	Fiesta	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2011	2018	Ford	Fiesta	-	Passenger Side	Beam	PTB	97040	A	-	-	-	-	-	16"
2007	2007	Ford	Five Hundred	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2007	2007	Ford	Five Hundred	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2005	2006	Ford	Five Hundred	-	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2005	2006	Ford	Five Hundred	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2009	2015	Ford	Flex	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2015	Ford	Flex	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2012	2018	Ford	Focus	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2012	2018	Ford	Focus	-	Passenger Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2008	2011	Ford	Focus	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2011	Ford	Focus	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2007	Ford	Focus	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2007	Ford	Focus	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2007	Ford	Focus	Hatchback	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2004	2007	Ford	Freestar	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2004	2007	Ford	Freestar	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C3	96150	Locking Clip	-	20"
2004	2007	Ford	Freestar	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2007	2007	Ford	Freestyle	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
2007	2007	Ford	Freestyle	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2005	2006	Ford	Freestyle	-	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2005	2006	Ford	Freestyle	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2013	2018	Ford	Fusion	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2013	2018	Ford	Fusion	-	Passenger Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2006	2012	Ford	Fusion	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2012	Ford	Fusion	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1971	1974	Ford	Galaxie 500	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1970	Ford	Galaxie	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1975	1982	Ford	Granada	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1970	1986	Ford	LTD	Inc.Wagon	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1985	Ford	LTD	Wagon	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1977	1979	Ford	LTD II	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2010	2018	Ford	Mustang	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2010	2018	Ford	Mustang	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2005	2009	Ford	Mustang	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2009	Ford	Mustang	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1994	2004	Ford	Mustang	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1979	1993	Ford	Mustang	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1979	1982	Ford	Mustang	-	Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1973	Ford	Mustang	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1969	1970	Ford	Mustang	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2007	2009	Ford	Mustang Shelby GT500	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2007	2009	Ford	Mustang Shelby GT500	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
1978	1980	Ford	Pinto	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1993	1997	Ford	Probe	-	Front & Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1992	Ford	Probe	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1966	1979	Ford	Ranchero	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1992	2011	Ford	Ranger	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1982	1991	Ford	Ranger	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2010	2015	Ford	Taurus	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2010	2015	Ford	Taurus	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2009	2009	Ford	Taurus	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2009	2009	Ford	Taurus	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2008	2008	Ford	Taurus	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2008	2008	Ford	Taurus	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
1996	2007	Ford	Taurus	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1996	2007	Ford	Taurus	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	2004	Ford	Taurus	Wagon	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	1995	Ford	Taurus	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1986	1991	Ford	Taurus	-	Front	Conv	Pin Arm 1/4"	97050	V	-	-	-	-	-	20"
2008	2009	Ford	Taurus X	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2008	2009	Ford	Taurus X	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
1986	1994	Ford	Tempo	-	Front	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
1985	1985	Ford	Tempo	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1984	1984	Ford	Tempo	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2002	2005	Ford	Thunderbird	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2005	Ford	Thunderbird	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1997	Ford	Thunderbird	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1989	1989	Ford	Thunderbird	-	Driver Side	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1989	1989	Ford	Thunderbird	-	Passenger Side	Conv	Pin Arm	97050	V	-	-	-	-	-	20"
1983	1988	Ford	Thunderbird	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1977	1982	Ford	Thunderbird	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1972	1976	Ford	Thunderbird	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1967	1971	Ford	Thunderbird	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1968	1976	Ford	Torino	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2016	2018	Ford	Transit	150	Driver Side	Beam	PTB	97070	A	-	-	-	-	-	28"
2016	2018	Ford	Transit	150	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2014	2015	Ford	Transit	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2014	2015	Ford	Transit	-	Passenger Side	Beam	PTB	97053	A	-	-	-	-	-	21"
2016	2018	Ford	Transit Connect	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2016	2018	Ford	Transit Connect	-	Passenger Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2016	2018	Ford	Transit Connect	-	Rear	Conv	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2014	2015	Ford	Transit Connect	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2014	2015	Ford	Transit Connect	-	Passenger Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2010	2013	Ford	Transit Connect	-	Driver Side	Conv	Hook slot 9x3/9x4	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2013	Ford	Transit Connect	-	Passenger Side	Conv	Hook slot 9x3/9x4	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	2003	Ford	Windstar	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1996	2003	Ford	Windstar	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C3	96150	Locking Clip	-	20"
1996	2003	Ford	Windstar	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	1995	Ford	Windstar	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1995	1995	Ford	Windstar	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2004	Ford	ZX2	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2004	Ford	ZX2	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2014	Freightliner	Sprinter	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2007	2014	Freightliner	Sprinter	-	Passenger Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2002	2006	Freightliner	Sprinter	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2006	Freightliner	Sprinter	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2017	2018	Genesis	G80	-	Driver Side	Hybrid	Hook 9x4	97065	V	95065	C1	96165	Locking Clip	-	26"
2017	2018	Genesis	G80	-	Passenger Side	Hybrid	Hook 9x4	97040	V	95040	C1	96140	Locking Clip	-	16"
2017	2018	Genesis	G90	-	Driver Side	Hybrid	Hook 9x4	97065	V	95065	C1	96165	Locking Clip	-	26"
2017	2018	Genesis	G90	-	Passenger Side	Hybrid	Hook 9x4	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	1997	Geo	Metro	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1997	Geo	Metro	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1989	1994	Geo	Metro	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1994	Geo	Metro	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1990	Geo	Metro	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1993	1997	Geo	Prizm	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1997	Geo	Prizm	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1990	1993	Geo	Storm	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1993	Geo	Storm	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1990	1997	Geo	Tracker	-	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1995	1997	Geo	Tracker	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1990	1992	Geo	Tracker	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2012	2016	GMC	Acadia	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2012	2016	GMC	Acadia	-	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2007	2011	GMC	Acadia	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2007	2011	GMC	Acadia	-	Passenger Side	Beam	PTB	97053	A	-	-	-	-	-	21"
1978	1987	GMC	Caballero	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2017	2018	GMC	Acadia	-	Passenger Side	Beam	Hook 9x4	97060	V	-	-	-	-	-	24"
2017	2018	GMC	Acadia	-	Passenger Side	Beam	Hook 9x4	97050	V	-	-	-	-	-	20"
2015	2018	GMC	Canyon	-	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2015	2018	GMC	Canyon	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
2004	2012	GMC	Canyon	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2012	GMC	Canyon	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2007	2009	GMC	Envoy	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2006	GMC	Envoy	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2006	GMC	Envoy	Exc.XUV	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1998	2000	GMC	Envoy	S-Series	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1995	GMC	G-Series (G1500/G2500/G3500)	Rally / Vandura	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1983	1992	GMC	G-Series Van (G1500)	Rally / Vandura	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1985	1991	GMC	Jimmy (K-Series)	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1995	2005	GMC	Jimmy (S-Series)	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	2005	GMC	Jimmy (S-Series)	-	Rear	Conv	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
1983	1994	GMC	Jimmy	(Incl. S15 Jimmy)	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2001	2002	GMC	Pickup, Sierra (C/K Series)	Exc.C/K2500-3500 SierraClassic	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	2000	GMC	Pickup, Sierra (C/K Series)	C1500 / C2500 / C3500/hd / K1500 / K2500 / K3500	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1988	1994	GMC	Pickup, Sierra (C/K Series)	C1500 / C2500 / C3500 / K1500 / K2500 / K3500	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1983	1986	GMC	Pickup, Sierra (C/K Series)	C1500 / C2500 / C3500 / K1500 / K2500 / K3500	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1988	1991	GMC	Pickup (R/V Series)	R2500 / R3500 / V3500	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1987	GMC	Pickup (R/V Series)	R1500 / R2500 / R3500 / V1500 / V2500 / V3500	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1991	1999	GMC	P-Series Van	P3500	Front	Conv	Hook	97045	V	-	-	-	-	-	18"
1985	2005	GMC	Safari	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1996	2015	GMC	Savana	1500/2500/3500/4500	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	GMC	Sierra	1500/2500HD/3500/Denali	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2007	2013	GMC	Sierra 1500/2500HD/3500HD/ Denali	Base / Denali SLE/ SL / WT	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2007	2007	GMC	Sierra 1500/ 1500HD/ 2500HD/3500	Sierra CLASSIC	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2006	GMC	Sierra 1500/2500HD/3500	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2004	GMC	Sierra 1500/2500HD/3500	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	2004	GMC	Sonoma	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1993	GMC	Sonoma	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1971	1977	GMC	Sprint Pickup	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1995	1999	GMC	Suburban	C/K1500,2500	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1994	GMC	Suburban	C/K1500,2500	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1991	GMC	Suburban	R/V1500,2500	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1991	1991	GMC	Syclone	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2014	2018	GMC	Sierra	1500/2500HD/3500/Denali	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2010	2018	GMC	Terrain	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2010	2018	GMC	Terrain	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
1992	1993	GMC	Typhoon	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2004	2008	GMC	TopKick (C4500 / C5500 / C6500 / C7500)	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2015	2018	GMC	Yukon / Yukon XL	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
2009	2014	GMC	Yukon / Yukon XL 1500 / Yukon XL 2500	-	Front	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2008	GMC	Yukon, Yukon XL, Denali, Denali XL	-	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2005	2006	GMC	Yukon / Yukon XL 1500 / Yukon XL 2500	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2006	GMC	Yukon / Yukon XL 1500 / Yukon XL 2500	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2000	2004	GMC	Yukon / Yukon XL 1500 / Yukon XL 2500	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2004	GMC	Yukon / Yukon XL 1500 / Yukon XL 2500	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	1999	GMC	Yukon	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2008	2016	Honda	Accord	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2008	2016	Honda	Accord	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2006	2007	Honda	Accord	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2006	2007	Honda	Accord	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2003	2005	Honda	Accord	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2003	2005	Honda	Accord	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1998	2002	Honda	Accord	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1998	2002	Honda	Accord	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1994	1997	Honda	Accord	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	1997	Honda	Accord	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1994	1997	Honda	Accord Wagon	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1990	1993	Honda	Accord	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1990	1993	Honda	Accord	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1989	Honda	Accord	-	Front & Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2017	2018	Honda	Accord	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2017	2018	Honda	Accord	-	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2016	2019	Honda	Civic	Coupe , Sedan (Inc. Hybrid & NG)	Driver Side	Beam	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Honda	Civic	Coupe , Sedan (Inc. Hybrid & NG)	Passenger Side	Beam	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2015	Honda	Civic	Coupe (Inc. Si)	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2012	2015	Honda	Civic	Coupe (Inc. Si)	Passenger Side	Hybrid	Hook 9x3	97060	V	-	-	96160	Locking Clip	-	24"
2016	2018	Honda	Civic	Coupe , Sedan (Inc. Hybrid & NG)	Rear	Beam	Hook 9x3	97035	V	95035	C1	-	-	-	14"
2008	2015	Honda	Civic	Sedan (Inc. Hvbrid & NG)	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2015	Honda	Civic	Sedan (Inc. Hybrid & NG)	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2011	Honda	Civic	Coupe	Driver Side	Beam	PTB	97070	A	-	-	-	-	-	28"
2006	2011	Honda	Civic	Coupe	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2001	2005	Honda	Civic	-	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2001	2005	Honda	Civic	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1996	2000	Honda	Civic	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	2000	Honda	Civic	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	2000	Honda	Civic	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1992	1995	Honda	Civic	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1995	Honda	Civic	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1988	1991	Honda	Civic	incl Wagon	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1991	Honda	Civic	incl Wagon	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1988	1991	Honda	Civic	Wagon	Rear	Conv	Hook	97040	V	-	-	-	-	-	16"
1984	1987	Honda	Civic	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1997	Honda	Civic del Sol	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1993	1997	Honda	Civic del Sol	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2002	2005	Honda	Civic Si	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2002	2005	Honda	Civic Si	-	Passenger Side	Conv	Hook slot 9x4	97040	V	95040	C3	-		-	16"
1984	1987	Honda	Civic Wagon	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2010	2015	Honda	Crosstour	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2010	2015	Honda	Crosstour	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2010	2015	Honda	Crosstour	-	Rear	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1988	1991	Honda	CRX	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1991	Honda	CRX	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1988	1991	Honda	CRX	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2007	2018	Honda	CR-V	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2007	2018	Honda	CR-V	-	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2002	2006	Honda	CR-V	-	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2002	2006	Honda	CR-V	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	2001	Honda	CR-V	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	2001	Honda	CR-V	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2015	Honda	CR-Z	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2011	2015	Honda	CR-Z	-	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2011	2015	Honda	CR-Z	-	Rear	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2003	2011	Honda	Element	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	1999	Honda	EV Plus	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1998	1999	Honda	EV Plus	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2010	Honda	FCX - Clarity	-	Front	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2016	2018	Honda	Fit	-	Driver Side	Beam	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2016	2018	Honda	Fit	-	Passenger Side	Beam	Hook 9x3	97035	V	-	-	96135	Locking Clip	-	14"
2009	2015	Honda	Fit	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2009	2015	Honda	Fit	-	Passenger Side	Hybrid	Hook 9x3	97035	V	-	-	96135	Locking Clip	-	14"
2007	2008	Honda	Fit	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2008	Honda	Fit	-	Passenger Side	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Honda	HRV	Crossover	Driver Side	Beam	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Honda	HRV	Crossover	Passenger Side	Beam	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2010	2015	Honda	Insight	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2015	Honda	Insight	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2014	Honda	Insight	-	Rear	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2006	Honda	Insight	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2006	Honda	Insight	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2006	Honda	Insight	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Honda	Odyssey	-	Driver Side	Beam	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Honda	Odyssey	-	Passenger Side	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2015	Honda	Odyssey	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2005	2015	Honda	Odyssey	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2004	Honda	Odyssey	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2004	Honda	Odyssey	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1999	2004	Honda	Odyssey	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1995	1998	Honda	Odyssey	-	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2002	Honda	Passport	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1998	1998	Honda	Passport	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1994	1997	Honda	Passport	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	Honda	Pilot	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Honda	Pilot	-	Passenger Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2015	Honda	Pilot	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2015	Honda	Pilot	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2003	2008	Honda	Pilot	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2003	2008	Honda	Pilot	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1997	2001	Honda	Prelude	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1997	2001	Honda	Prelude	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1996	Honda	Prelude	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1996	Honda	Prelude	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1988	1991	Honda	Prelude	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1991	Honda	Prelude	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2016	2018	Honda	Ridgeline	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Honda	Ridgeline	-	Passenger Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2014	Honda	Ridgeline	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2008	Honda	Ridgeline	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2008	Honda	Ridgeline	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2009	Honda	S2000	-	Driver Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1999	2009	Honda	S2000	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2009	Hummer	H2 / H2 SUT	-	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2006	2010	Hummer	H3	-	Driver Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2006	2010	Hummer	H3	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2009	2010	Hummer	H3T	-	Driver Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2009	2010	Hummer	H3T	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2012	2018	Hyundai	Accent	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2012	2018	Hyundai	Accent	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2007	2011	Hyundai	Accent	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2011	Hyundai	Accent	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2006	2006	Hyundai	Accent	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2006	Hyundai	Accent	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2001	2005	Hyundai	Accent	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2005	Hyundai	Accent	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2005	Hyundai	Accent	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2000	2000	Hyundai	Accent	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2000	Hyundai	Accent	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2000	2000	Hyundai	Accent	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	1999	Hyundai	Accent	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1999	Hyundai	Accent	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	1999	Hyundai	Accent	-	Rear	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1995	Hyundai	Accent	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1995	Hyundai	Accent	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2017	Hyundai	Azera	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2012	2017	Hyundai	Azera	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2006	2011	Hyundai	Azera	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2011	Hyundai	Azera	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2016	2018	Hyundai	Elantra	Sedan	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Hyundai	Elantra	Sedan	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Hyundai	Elantra	GT (Hatchback)	Driver Side	Conv	Hook 9x3	97070	V	-	C1	96170	Locking Clip	-	28"
2016	2018	Hyundai	Elantra	GT (Hatchback)	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2011	2015	Hyundai	Elantra	-	Driver Side	Conv	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2011	2015	Hyundai	Elantra	-	Passenger Side	Conv	Hook 9x3	97035	V	-	-	96135	Locking Clip	-	14"
2007	2010	Hyundai	Elantra	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"

PIAA

YEAR (Range)									SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2007	2010	Hyundai	Elantra	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2006	Hyundai	Elantra	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2006	Hyundai	Elantra	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2006	Hyundai	Elantra	-	Rear	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	2000	Hyundai	Elantra	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	2000	Hyundai	Elantra	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1995	Hyundai	Elantra	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	1995	Hyundai	Elantra	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1992	Hyundai	Elantra	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	1992	Hyundai	Elantra	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2012	Hyundai	Elantra Touring	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2012	Hyundai	Elantra Touring	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	2000	Hyundai	Elantra Wagon	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	2000	Hyundai	Elantra Wagon	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2008	Hyundai	Entourage	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2007	2008	Hyundai	Entourage	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2015	Hyundai	Equus	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2012	2015	Hyundai	Equus	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2011	2011	Hyundai	Equus	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2011	2011	Hyundai	Equus	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
1990	1994	Hyundai	Excel	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1990	1994	Hyundai	Excel	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1988	1989	Hyundai	Excel	-	Front & Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1986	1987	Hyundai	Excel	-	Front & Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2015	2015	Hyundai	Genesis	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2015	2015	Hyundai	Genesis	-	Passenger Side	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2012	2014	Hyundai	Genesis	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2012	2014	Hyundai	Genesis	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2009	2011	Hyundai	Genesis	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2009	2011	Hyundai	Genesis	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2010	2015	Hyundai	Genesis Coupe	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2015	Hyundai	Genesis Coupe	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2018	Hyundai	Santa Fe	-	Driver Side	Conv	Hook 9x4	97065	V	95065	C1	-	-	-	26"
2013	2018	Hyundai	Santa Fe	-	Passenger Side	Conv	Hook 9x4	97035	V	95035	C1	-	-	-	14"
2007	2012	Hyundai	Santa Fe	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2012	Hyundai	Santa Fe	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2006	Hyundai	Santa Fe	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2006	Hyundai	Santa Fe	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2004	Hyundai	Santa Fe	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2004	Hyundai	Santa Fe	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2014	Hyundai	Santa Fe Sport	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
1991	1995	Hyundai	Scoupe	-	Driver Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1995	Hyundai	Scoupe	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2011	2018	Hyundai	Sonata	Inc. Hybrid	Driver Side	Hybrid	Hook 9x4	97065	V	95065	C1	-	-	-	26"
2011	2018	Hyundai	Sonata	Inc. Hybrid	Passenger Side	Hybrid	Hook 9x4	97045	V	95045	C1	-	-	-	18"
2006	2010	Hyundai	Sonata	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2010	Hyundai	Sonata	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2005	Hyundai	Sonata	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2005	Hyundai	Sonata	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1998	Hyundai	Sonata	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1994	Hyundai	Sonata	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1994	Hyundai	Sonata	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1985	1987	Hyundai	Stellar	Canada	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2008	Hyundai	Tiburon	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2008	Hyundai	Tiburon	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1999	2005	Hyundai	Tiburon	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2005	Hyundai	Tiburon	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	2006	Hyundai	Tiburon	-	Rear	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2016	2017	Hyundai	Tucson	-	Driver Side	Conv	Hook 9x4	97065	V	95065	C1	-	-	-	26"
2016	2017	Hyundai	Tucson	-	Passenger Side	Conv	Hook 9x4	97040	V	95040	C1	-	-	-	16"
2005	2015	Hyundai	Tucson	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2015	Hyundai	Tucson	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2012	2018	Hyundai	Veloster	-	Driver Side	Conv	Hook 9x4	97065	V	95065	C1	-	-	-	26"
2012	2018	Hyundai	Veloster	-	Passenger Side	Conv	Hook 9x4	97040	V	95040	C1	-	-	-	16"
2008	2012	Hyundai	Veracruz	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2008	2012	Hyundai	Veracruz	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2001	2005	Hyundai	XG300/350	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2005	Hyundai	XG300/350	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2011	2012	Infiniti	EX35	-	Driver Side	Hybrid	Hook 9x3	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2011	2012	Infiniti	EX35	-	Passenger Side	Hybrid	Hook 9x3	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2008	2010	Infiniti	EX35	-	Driver Side	Hybrid	Hook 9x3	97055	V	-	-	96155	Need 94005	Side Mount Hook	22"
2008	2010	Infiniti	EX35	-	Passenger Side	Hybrid	Hook 9x3	97045	V	-	-	96145	Need 94005	Side Mount Hook	18"
2013	2013	Infiniti	EX37	-	Driver Side	Hybrid	Hook slot 9x3/9x4	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2013	2013	Infiniti	EX37	-	Passenger Side	Hybrid	Hook slot 9x3/9x4	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2011	2012	Infiniti	FX35	-	Driver Side	Hybrid	Hook slot 9x3/9x4	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2011	2012	Infiniti	FX35	-	Passenger Side	Hybrid	Hook slot 9x3/9x4	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2009	2010	Infiniti	FX35	-	Driver Side	Hybrid	Hook 9x3	97055	V	-	-	96155	Need 94005	Side Mount Hook	22"
2009	2010	Infiniti	FX35	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2003	2008	Infiniti	FX35	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2008	Infiniti	FX35	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2013	Infiniti	FX37	-	Driver Side	Hybrid	Hook 9x3	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2013	2013	Infiniti	FX37	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2003	2008	Infiniti	FX45	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2008	Infiniti	FX45	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2011	2013	Infiniti	FX50	-	Driver Side	Hybrid	Hook 9x3	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2011	2013	Infiniti	FX50	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2009	2010	Infiniti	FX50	-	Driver Side	Hybrid	Hook 9x3	97055	V	-	-	96155	Need 94005	Side Mount Hook	22"
2009	2010	Infiniti	FX50	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
1999	2002	Infiniti	G20	-	Driver Side	conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1999	2002	Infiniti	G20	-	Passenger Side	conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1996	Infiniti	G20	-	Driver Side	Conventional	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1991	1996	Infiniti	G20	-	Passenger Side	Conventional	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2012	Infiniti	G25	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2011	2012	Infiniti	G25	-	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2007	2008	Infiniti	G35	Sedan	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2007	2008	Infiniti	G35	Sedan	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2003	2006	Infiniti	G35	Sedan	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2006	Infiniti	G35	Sedan	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2003	2007	Infiniti	G35	Coupe	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2003	2007	Infiniti	G35	Coupe	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2010	2013	Infiniti	G37	Sedan	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2010	2013	Infiniti	G37	Sedan	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2010	2013	Infiniti	G37	Coupe	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2010	2013	Infiniti	G37	Coupe	Passenger Side	Hybrid	Hook 9x3	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2000	2001	Infiniti	I30	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2000	2001	Infiniti	I30	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1996	1999	Infiniti	I30	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1996	1999	Infiniti	I30	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2002	2004	Infiniti	I35	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2002	2004	Infiniti	I35	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2013	2013	Infiniti	IPL	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2013	Infiniti	IPL	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2013	2013	Infiniti	JX35	-	Driver Side	Conv	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2013	2013	Infiniti	JX35	-	Passenger Side	Conv	Hook 9x3	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
1990	1992	Infiniti	M30	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1990	1992	Infiniti	M30	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2006	2010	Infiniti	M35	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2010	Infiniti	M35	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2012	2013	Infiniti	M35h	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2012	2013	Infiniti	M35h	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2011	2013	Infiniti	M37	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2011	2013	Infiniti	M37	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2006	2010	Infiniti	M45	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2010	Infiniti	M45	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2003	2004	Infiniti	M45	-	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2003	2004	Infiniti	M45	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2013	Infiniti	M56	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2011	2013	Infiniti	M56	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2015	2015	Infiniti	Q40	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2015	2015	Infiniti	Q40	-	Passenger Side	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2006	Infiniti	Q45	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2002	2006	Infiniti	Q45	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	2001	Infiniti	Q45	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	2001	Infiniti	Q45	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1990	1996	Infiniti	Q45	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2014	2018	Infiniti	Q50	-	Driver Side	Hybrid	Hook 9x4	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2014	2018	Infiniti	Q50	-	Passenger Side	Hybrid	Hook 9x4	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2014	2018	Infiniti	Q60	-	Driver Side	Hybrid	Hook 9x4	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2014	2018	Infiniti	Q60	-	Passenger Side	Hybrid	Hook 9x4	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2014	2018	Infiniti	Q70	-	Driver Side	Hybrid	Hook 9x4	97065	V	95065	C1	-	-	-	26"
2014	2018	Infiniti	Q70	-	Passenger Side	Hybrid	Hook 9x4	97048	V	95048	C1	-	-	-	19"
1997	2003	Infiniti	QX4	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	2003	Infiniti	QX4	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2016	2018	Infiniti	QX30	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2016	2018	Infiniti	QX30	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2014	2018	Infiniti	QX50	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2014	2018	Infiniti	QX50	-	Passenger Side	Hybrid	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2011	2013	Infiniti	QX56	-	Driver Side	Hybrid	Hook 9x3	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2011	2013	Infiniti	QX56	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2004	2010	Infiniti	QX56	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"

PIAA

YEAR (Range)									SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2004	2010	Infiniti	QX56	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	Infiniti	QX60	-	Driver Side	Hybrid	Hook 9x4	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2014	2018	Infiniti	QX60	-	Passenger Side	Hybrid	Hook 9x4	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2014	2018	Infiniti	QX70	-	Driver Side	Hybrid	Hook 9x4	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2014	2018	Infiniti	QX70	-	Passenger Side	Hybrid	Hook 9x4	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2014	2018	Infiniti	QX80	-	Driver Side	Hybrid	Hook 9x3	97060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2014	2018	Infiniti	QX80	-	Passenger Side	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
1998	2000	Isuzu	Amigo	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1989	1994	Isuzu	Amigo	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2008	Isuzu	Ascender	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2006	Isuzu	Ascender	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2006	Isuzu	Ascender	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2004	Isuzu	Axiom	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2002	2004	Isuzu	Axiom	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1996	2000	Isuzu	Hombre	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2006	2006	Isuzu	i-280 / i-350	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2006	Isuzu	i-280 / i-350	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2007	2008	Isuzu	i-290 / i-370	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2008	Isuzu	i-290 / i-370	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1990	1992	Isuzu	Impulse	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	1992	Isuzu	Impulse	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1999	Isuzu	Oasis	-	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1981	1995	Isuzu	Pickup	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1998	2004	Isuzu	Rodeo	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1997	Isuzu	Rodeo	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1993	Isuzu	Stylus	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1991	1993	Isuzu	Stylus	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	2002	Isuzu	Trooper	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	2002	Isuzu	Trooper	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1984	1991	Isuzu	Trooper / Trooper II	-	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1984	1991	Isuzu	Trooper / Trooper II	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1999	2001	Isuzu	VehiCROSS	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2001	Isuzu	VehiCROSS	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2018	2018	Jaguar	E- Pace	-	Driver Side	Hybrid	PTB	97065	B	-	-	-	-	-	26"
2018	2018	Jaguar	E- Pace	-	Passenger Side	Hybrid	PTB	97050	B	-	-	-	-	-	20"
2018	2018	Jaguar	F- Pace	-	Driver Side	Hybrid	PTB	97065	B	-	-	-	-	-	26"
2018	2018	Jaguar	F- Pace	-	Passenger Side	Hybrid	PTB	97048	B	-	-	-	-	-	19"
2016	2016	Jaguar	F-Type	-	Driver Side	Hybrid	Hook 9x4	97055	V	95055	C1	-	-	-	22"
2016	2016	Jaguar	F-Type	-	Passenger Side	Hybrid	Hook 9x4	97053	V	95053	C1	-	-	-	21"
2014	2015	Jaguar	F-Type	-	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2014	2015	Jaguar	F-Type	-	Passenger Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
2002	2003	Jaguar	S-Type	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2002	2003	Jaguar	S-Type	-	Passenger Side	Conv	Hook slot 9x4	97048	V	95048	C3	-	-	-	19"
2000	2001	Jaguar	S-Type	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2008	Jaguar	X-Type	-	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2002	2008	Jaguar	X-Type	-	Passenger Side	Conv	Hook slot 9x4	97048	V	95048	C3	-	-	-	19"
2018	2018	Jaguar	XE	-	Driver Side	Hybrid	PTB	97065	B	-	-	-	-	-	26"
2018	2018	Jaguar	XE	-	Passenger Side	Hybrid	PTB	97043	B	-	-	-	-	-	17"
2016	2018	Jaguar	XF	-	Driver Side	Beam	PTB	97065	B	-	-	-	-	-	26"
2016	2018	Jaguar	XF	-	Passenger Side	Beam	PTB	97043	B	-	-	-	-	-	17"
2009	2015	Jaguar	XF	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2009	2015	Jaguar	XF	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2010	2015	Jaguar	XFR	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2010	2015	Jaguar	XFR	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2011	2018	Jaguar	XJ	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2011	2018	Jaguar	XJ	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
1988	2003	Jaguar	XJ6, XJ8, Vanden Plas	-	Front (Single Blade)	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1988	1996	Jaguar	XJ12	-	Front (Single Blade)	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2015	Jaguar	XK	Coupe & Convertible	Driver Side	Hybrid	Hook	97055	V	-	-	-	-	-	22"
2007	2015	Jaguar	XK	Coupe & Convertible	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2014	Jaguar	XKR	Coupe & Convertible	Driver Side	Hybrid	Hook	97055	V	-	-	-	-	-	22"
2007	2014	Jaguar	XKR	Coupe & Convertible	Passenger Side	Hybrid	Hook	97053	V	-	-	-	-	-	21"
1997	2006	Jaguar	XK8, XKR	-	Front	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
2014	2018	Jeep	Cherokee	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C3	96165	Locking Clip	-	26"
2014	2018	Jeep	Cherokee	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	2002	Jeep	Cherokee	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1984	1996	Jeep	Cherokee	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1976	1983	Jeep	Cherokee	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1986	1992	Jeep	Comanche	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2006	2010	Jeep	Commander	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2018	Jeep	Compass	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2018	Jeep	Compass	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1970	1973	Jeep	Gladiator	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2011	2018	Jeep	Grand Cherokee	-	Driver Side	Hybrid	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2018	Jeep	Grand Cherokee	-	Passenger Side	Hybrid	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2005	2010	Jeep	Grand Cherokee	-	Front	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1999	2004	Jeep	Grand Cherokee	-	Front	Conv	Hook slot 9x4	97053	V	95053	C4	-	-	-	21"
1993	1998	Jeep	Grand Cherokee	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1993	Jeep	Grand Wagoneer	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1984	1991	Jeep	Grand Wagoneer	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1982	Jeep	Laredo	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2008	2012	Jeep	Liberty	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2002	2007	Jeep	Liberty	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2007	2016	Jeep	Patriot	-	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1974	1988	Jeep	Pickup	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2007	2016	Jeep	Patriot	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2015	2018	Jeep	Renegade	-	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2015	2018	Jeep	Renegade	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
1997	2004	Jeep	TJ	Canada	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1984	1990	Jeep	Wagoneer	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1974	1983	Jeep	Wagoneer	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2007	2017	Jeep	Wrangler	All Models	Driver Side	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2007	2017	Jeep	Wrangler	All Models	Passenger Side	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2005	2006	Jeep	Wrangler	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1997	2004	Jeep	Wrangler	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1988	1995	Jeep	Wrangler	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1988	1995	Jeep	YJ	Canada	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2004	2009	Kia	Amanti	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2004	2009	Kia	Amanti	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2010	Kia	Borrego	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2010	Kia	Borrego	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2018	Kia	Cadenza	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2018	Kia	Cadenza	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	1996	Kia	Credos	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1996	1996	Kia	Credos	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2017	2018	Kia	Forte	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2017	2018	Kia	Forte	-	Passenger Side	Hybrid	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2014	2015	Kia	Forte	Inc. Koupe & 5	Driver Side	Conv	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2014	2015	Kia	Forte	Inc. Koupe & 5	Passenger Side	Conv	Hook 9x3	97035	V	-	-	96135	Locking Clip	-	14"
2010	2013	Kia	Forte / Forte Koup	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2013	Kia	Forte / Forte Koup	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2015	2018	Kia	K900	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2015	2018	Kia	K900	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2004	Kia	Magentis	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2004	Kia	Magentis	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2018	2018	Kia	Niro	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2018	2018	Kia	Niro	-	Passenger Side	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Kia	Optima	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Kia	Optima	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2015	Kia	Optima	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2015	Kia	Optima	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2006	Kia	Optima	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2006	Kia	Optima	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2012	2018	Kia	Rio / Rio 5	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2012	2018	Kia	Rio / Rio 5	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2006	2011	Kia	Rio / Rio 5	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2011	Kia	Rio / Rio 5	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2001	2005	Kia	Rio / Rio 5	-	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2001	2005	Kia	Rio / Rio 5	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2010	Kia	Rondo	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2007	2010	Kia	Rondo	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Kia	Sedona	EX, SXL	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Kia	Sedona	EX, SXL	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2006	2015	Kia	Sedona	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2006	2015	Kia	Sedona	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2002	2005	Kia	Sedona	-	Front	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2005	Kia	Sedona	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1993	2001	Kia	Sephia	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1993	2001	Kia	Sephia	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1993	1997	Kia	Sephia	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	Kia	Sorento	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Kia	Sorento	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2011	2015	Kia	Sorento	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2015	Kia	Sorento	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2009	Kia	Sorento	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2003	2009	Kia	Sorento	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2010	2018	Kia	Soul	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2018	Kia	Soul	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2009	Kia	Spectra / Spectra 5	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2009	Kia	Spectra / Spectra 5	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
2000	2004	Kia	Spectra / Spectra 5	-	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2000	2004	Kia	Spectra / Spectra 5	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2004	Kia	Spectra / Spectra 5	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2017	2018	Kia	Sportage	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2017	2018	Kia	Sportage	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2011	2015	Kia	Sportage	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2015	Kia	Sportage	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2010	Kia	Sportage	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2010	Kia	Sportage	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	2002	Kia	Sportage	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	2002	Kia	Sportage	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1987	1997	Lada	Samara	Canada	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1989	1990	Laforza	LaForza	Canada	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1989	1990	Laforza	LaForza	Canada	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1999	1999	Land Rover	Discovery	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1998	Land Rover	Discovery	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2017	2018	Land Rover	Discovery	-	Driver Side	Hybrid	PTB	97060	A	95060	C1	96160	Locking Clip	-	24"
2017	2018	Land Rover	Discovery	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2015	2018	Land Rover	Discovery Sport	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2015	2018	Land Rover	Discovery Sport	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2002	2005	Land Rover	Freelander	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2005	Land Rover	Freelander	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2008	2015	Land Rover	LR2	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2008	2015	Land Rover	LR2	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2005	2009	Land Rover	LR3	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2009	Land Rover	LR3	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2010	2011	Land Rover	LR4	-	Front	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2010	2011	Land Rover	LR4	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2013	2018	Land Rover	Range Rover / Range Rover Sport	-	Driver Side	Hybrid	PTB	97060	A	95060	C1	96160	Locking Clip	-	24"
2013	2018	Land Rover	Range Rover / Range Rover Sport	-	Passenger Side	Hybrid	PTB	97050	A	95050	C1	96150	Locking Clip	-	20"
2013	2015	Land Rover	Range Rover	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2013	2015	Land Rover	Range Rover Sport	-	Rear	Conv	Hook 9x3	97038	V	95038	C3	96138	Locking Clip	-	15"
2002	2012	Land Rover	Range Rover	-	Driver Side	Conv	Hook	97065	V	-	-	-	-	-	26"
2002	2012	Land Rover	Range Rover	-	Passenger Side	Conv	Hook	97065	V	-	-	-	-	-	26"
2002	2012	Land Rover	Range Rover	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	2001	Land Rover	Range Rover	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1996	2001	Land Rover	Range Rover	-	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1995	1995	Land Rover	Range Rover	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1995	Land Rover	Range Rover	-	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2017	2017	Land Rover	Range Rover / Range Rover Sport	-	Driver Side	Beam	Gen2V5	97060	F	-	-	-	-	-	24"
2017	2017	Land Rover	Range Rover / Range Rover Sport	-	Passenger Side	Beam	Gen2V5	97050	F	-	-	-	-	-	20"
2013	2018	Land Rover	Range Rover / Range Rover Sport	-	Rear	Hybrid	I&L	97043	A	95043	C1	96150	Locking Clip	-	17"
2012	2018	Land Rover	Range Rover Evoque	-	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2012	2018	Land Rover	Range Rover Evoque	-	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2006	2012	Land Rover	Range Rover Sport	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2012	Land Rover	Range Rover Sport	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2011	2016	Lexus	CT	CT200h	Driver Side	Hybrid	Hook slot 9x3/9x4	97065	V	95065	C1	96165	Locking Clip	-	26"
2011	2016	Lexus	CT	CT200h	Passenger Side	Hybrid	Hook slot 9x3/9x4	97045	V	95045	C1	96145	Locking Clip	-	18"
2013	2018	Lexus	ES	ES300h, ES350 (Inc. Hybrid)	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2018	Lexus	ES	ES300h, ES350 (Inc. Hybrid)	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2012	Lexus	ES	ES350	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2012	Lexus	ES	ES350	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2002	2006	Lexus	ES	ES300, ES330	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2006	Lexus	ES	ES300, ES330	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	2001	Lexus	ES	ES300	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	2001	Lexus	ES	ES300	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1996	Lexus	ES	ES300	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1996	Lexus	ES	ES300	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2013	2018	Lexus	GS	GS350, GS450h (Inc. Hybrid)	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2018	Lexus	GS	GS350, GS450h (Inc. Hybrid)	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2006	2011	Lexus	GS	GS300, GS350, GS430, GS450h, GS460	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2011	Lexus	GS	GS300, GS350, GS430, GS450h, GS460	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1998	2005	Lexus	GS	GS300, GS400, GS430	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1998	2005	Lexus	GS	GS300, GS400, GS430	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1997	Lexus	GS	GS300	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1993	1997	Lexus	GS	GS300	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2010	2018	Lexus	GX	GX460	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2018	Lexus	GX	GX460	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2009	Lexus	GX	GX470	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2009	Lexus	GX	GX470	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2010	2012	Lexus	HS	HS250h	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2012	Lexus	HS	HS250h	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2014	2015	Lexus	IS	IS250, IS350 (Incl. C, CF Sport, F Sport)	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2014	2015	Lexus	IS	IS250, IS350 (Incl. C, CF Sport, F Sport)	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2014	2015	Lexus	IS C	IS250, IS350 Convertible	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2015	Lexus	IS C	IS250, IS350 Convertible	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2006	2013	Lexus	IS	IS250, IS350 (Incl. C)	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
															"
															"
2006	2013	Lexus	IS	IS250, IS350 (Incl. C)	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2005	Lexus	IS	IS300	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2005	Lexus	IS	IS300	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2008	2014	Lexus	IS F	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2014	Lexus	IS F	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2007	2015	Lexus	LS	LS460, LS600h (Incl. Hybrid)	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2015	Lexus	LS	LS460, LS600h (Incl. Hybrid)	Passenger Side	Hybrid	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
															"
															"
															"
2001	2006	Lexus	LS	LS430	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2001	2006	Lexus	LS	LS430	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1990	2000	Lexus	LS	LS400	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	2000	Lexus	LS	LS400	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Lexus	IS	300, 350	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2016	2018	Lexus	IS	300, 350	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2018	2018	Lexus	LC	500	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2018	2018	Lexus	LC	500	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2013	2018	Lexus	LX	LX570	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2013	2018	Lexus	LX	LX570	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2011	Lexus	LX	LX570	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2008	2011	Lexus	LX	LX570	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2007	Lexus	LX	LX470	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2000	2007	Lexus	LX	LX470	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2007	Lexus	LX	LX470	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1998	1999	Lexus	LX	LX470	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	1999	Lexus	LX	LX470	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1996	1997	Lexus	LX	LX450	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	1997	Lexus	LX	LX450	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2018	2018	Lexus	NX	300, 300h	Driver Side	Hybrid	PTB	97065	A	-	-	-	-	-	26"
2018	2018	Lexus	NX	300, 300h	Passenger Side	Hybrid	PTB	97040	A	-	-	-	-	-	16"
2015	2017	Lexus	NX	NX 300h, NX 200 TURBO F SPORT	Driver Side	Beam	Gen2V5	97065	F	-		-			26"
2015	2017	Lexus	NX	NX 300h, NX 200 TURBO F SPORT	Passenger Side	Beam	Gen2V5	97040	F	-		-			16"
2015	2018	Lexus	RC	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2015	2018	Lexus	RC	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	Lexus	RX	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2016	2018	Lexus	RX	-	Passenger Side	Beam	PTB	97053	A	-	-	-	-	-	21"
2010	2015	Lexus	RX	RX350, RX450h	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2015	Lexus	RX	RX350, RX450h	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2009	Lexus	RX	RX330, RX350, RX400h	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2004	2009	Lexus	RX	RX330, RX350, RX400h	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2003	Lexus	RX	RX300	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2003	Lexus	RX	RX300	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1999	2003	Lexus	RX	RX300	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2010	Lexus	SC	SC430	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2010	Lexus	SC	SC430	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	2000	Lexus	SC	SC300, SC400	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	2000	Lexus	SC	SC300, SC400	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2005	Lincoln	Aviator	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2005	Lincoln	Aviator	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2002	Lincoln	Blackwood	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2016	2018	Lincoln	Continental	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2016	2018	Lincoln	Continental	-	Passenger Side	Beam	I&L	97050	A	-		-	-	-	20"
1998	2002	Lincoln	Continental	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
1998	2002	Lincoln	Continental	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	1997	Lincoln	Continental	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1991	Lincoln	Continental	-	Front	Conv	Pin Arm 1/4"	97050	V	-	-	-	-	-	20"
1973	1980	Lincoln	Continental	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1972	Lincoln	Continental	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
2000	2006	Lincoln	LS	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2000	2006	Lincoln	LS	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1993	1998	Lincoln	Mark VIII	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1972	1992	Lincoln	Mark IV, V, VI, VII	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1968	1971	Lincoln	Mark III	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2006	2008	Lincoln	Mark LT	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2015	2018	Lincoln	MKC	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"

PIAA

YEAR (Range)								SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2015	2018	Lincoln	MKC	-	Passenger Side	Beam	I&L	97040	A	-			-	-	16"
2009	2015	Lincoln	MKS	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2009	2015	Lincoln	MKS	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2010	2015	Lincoln	MKT	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2010	2015	Lincoln	MKT	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2017	2018	Lincoln	MKC	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2017	2018	Lincoln	MKC	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2016	2018	Lincoln	MKX	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2016	2018	Lincoln	MKX	-	Passenger Side	Beam	I&L	97045	A	-	-	-	-	-	18"
2007	2015	Lincoln	MKX	-	Driver Side	Conv	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2007	2015	Lincoln	MKX	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2018	Lincoln	MKZ	-	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2013	2018	Lincoln	MKZ	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2007	2012	Lincoln	MKZ	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2012	Lincoln	MKZ	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2008	2018	Lincoln	Navigator	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2008	Lincoln	Navigator	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2003	2007	Lincoln	Navigator	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2007	Lincoln	Navigator	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1998	2002	Lincoln	Navigator	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	2002	Lincoln	Navigator	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1993	2011	Lincoln	Town Car	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1992	Lincoln	Town Car	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1981	1989	Lincoln	Town Car	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1977	1980	Lincoln	Versailles	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2006	2006	Lincoln	Zephyr	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2006	Lincoln	Zephyr	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2004	2011	Lotus	Elise	-	Driver Side (Front)	Conv	Hook	97065	V			-	-	-	26"
2005	2010	Lotus	Exige	-	Driver Side (Front)	Conv	Hook	97065	V	-	-	-	-	-	26"
2010	2013	Lotus	Evora	-	Driver Side (Front)	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
1986	1994	Maserati	228	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2004	Maserati	3200 GT / Coupe	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1989	1989	Maserati	425i, 430	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1981	1994	Maserati	BiTurbo	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2015	Maserati	Ghibli	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2013	2015	Maserati	Ghibli	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
2013	2015	Maserati	Quattroporte	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2013	2015	Maserati	Quattroporte	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
1987	1994	Maserati	Quattroporte	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1990	1994	Maserati	Shamal	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1990	Maserati	Spider	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2002	2004	Maserati	Spyder	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2011	2015	Mazda	2	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2015	Mazda	2	-	Passenger Side	Conv	Hook slot 9x3/9x4	97035	V	95035	C1	96135	Locking Clip	-	14"
2010	2018	Mazda	3	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2018	Mazda	3	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2004	2009	Mazda	3	-	Front Left	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2004	2009	Mazda	3	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1990	1995	Mazda	323	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1990	1995	Mazda	323	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1986	1989	Mazda	323	-	Front & Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2006	2015	Mazda	5	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2006	2015	Mazda	5	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2009	2018	Mazda	6	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2018	Mazda	6	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2003	2008	Mazda	6	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2008	Mazda	6	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2004	2007	Mazda	6	Hatchback	Rear	Conv	Hook	97050	V	-	-	-	-	-	20"
1998	2003	Mazda	626	-	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1998	2003	Mazda	626	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1993	1997	Mazda	626	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1993	1997	Mazda	626	-	Front Right	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1992	Mazda	626	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1988	1992	Mazda	626	-	Rear	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1986	1987	Mazda	626	-	Front & Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1995	Mazda	929	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1995	Mazda	929	-	Front Right	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1991	Mazda	929	-	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1991	Mazda	929	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1988	2009	Mazda	B-Series Truck	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	Mazda	CX-3	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2018	Mazda	CX-3	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2013	2018	Mazda	CX-5	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2013	2018	Mazda	CX-5	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2017	2017	Mazda	CX-5	-	Driver Side	Beam	Hook 9x3	97060	F	-	-	-	-	-	24"
2017	2017	Mazda	CX-5	-	Passenger Side	Beam	Hook 9x3	97045	F	-	-	-	-	-	18"
2007	2012	Mazda	CX-7	-	Front Left	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2007	2012	Mazda	CX-7	-	Front Right	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2007	2015	Mazda	CX-9	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2007	2015	Mazda	CX-9	-	Passenger Side	Hybrid	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2007	2009	Mazda	3/3 Sport	MazdaSpeed	Front Left	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2009	Mazda	3/3 Sport	MazdaSpeed	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1995	2002	Mazda	Millenia	-	Front Left	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	2002	Mazda	Millenia	-	Front Right	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2006	Mazda	MPV	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2000	2006	Mazda	MPV	-	Front Right	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2000	2006	Mazda	MPV	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1989	1999	Mazda	MPV	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1989	1999	Mazda	MPV	-	Front Right	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1999	Mazda	MPV	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1989	1995	Mazda	MPV	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	1996	Mazda	MX-3	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1996	Mazda	MX-3	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1996	Mazda	MX-3	-	Rear	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2017	2018	Mazda	CX-9	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2017	2018	Mazda	CX-9	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2017	Mazda	CX-9	-	Driver Side	Beam	Gen2V5	97060	F	-		-			24"
2016	2017	Mazda	CX-9	-	Passenger Side	Beam	Gen2V5	97045	F						18"
2016	2018	Mazda	MX-5 Miata	-	Driver Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	Mazda	MX-5 Miata	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2006	2015	Mazda	MX-5 Miata	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1990	2005	Mazda	MX-5 Miata	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1997	Mazda	MX-6	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1988	1992	Mazda	MX-6	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1994	Mazda	Navajo	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2000	2002	Mazda	Premacy	-	Front Left	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2000	2002	Mazda	Premacy	-	Front Right	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1999	2004	Mazda	Protégé	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1999	2004	Mazda	Protégé	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1990	1998	Mazda	Protégé	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1990	1998	Mazda	Protégé	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2002	2003	Mazda	Protégé 5	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2002	2003	Mazda	Protégé 5	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1974	1978	Mazda	RX-4	-	Front	Conv	Pin Arm	97043	V	-	-	-	-	-	17"
1993	1995	Mazda	RX-7	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1993	Mazda	RX-7	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1986	1992	Mazda	RX-7	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1986	1992	Mazda	RX-7	-	Rear	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2011	Mazda	RX-8	-	Front Left	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2011	Mazda	RX-8	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2012	Mazda	Speed 3	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2012	2012	Mazda	Speed 3	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2008	2010	Mazda	Tribute	-	Front	Beam	I&L	97050	A	-	-	-	-	-	20"
2005	2007	Mazda	Tribute	-	Front Left	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2007	Mazda	Tribute	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2004	Mazda	Tribute	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1993	Mercedes-Benz	190E, 190D (W201)	-	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1984	1985	Mercedes-Benz	190E, 190D (W201)	-	Front (Single Blade)	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1977	1978	Mercedes-Benz	230	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1974	1976	Mercedes-Benz	230	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1977	1983	Mercedes-Benz	240D	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1974	1976	Mercedes-Benz	240D	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1968	1972	Mercedes-Benz	250	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1987	1989	Mercedes-Benz	260E (W124)	-	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1977	1981	Mercedes-Benz	280, CE, E	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1973	1976	Mercedes-Benz	280, C	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1975	1980	Mercedes-Benz	280S, SE	-	Driver Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1975	1980	Mercedes-Benz	280S, SE	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1988	1993	Mercedes-Benz	300 - CE, D, E, SD, SE, SL, TD, TE (W124)	-	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1988	1993	Mercedes-Benz	300 TE (W124)	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1986	1987	Mercedes-Benz	300, E, D, CE, CD, TD, TE (W124)	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1977	1985	Mercedes-Benz	300CD, D, TD	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1979	1985	Mercedes-Benz	300TD	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1975	1976	Mercedes-Benz	300D	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	1993	Mercedes-Benz	300SD, SE (W140)	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	-	-	-	-	-	24"
1992	1993	Mercedes-Benz	300SD, SE, SL (W140)	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1978	1980	Mercedes-Benz	300SD	-	Driver Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1978	1980	Mercedes-Benz	300SD	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
1968	1973	Mercedes-Benz	300SEL	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1990	1993	Mercedes-Benz	300SL	Convertible	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1981	1985	Mercedes-Benz	380SL, SLC	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1993	Mercedes-Benz	400E (W 124)	-	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1992	1992	Mercedes-Benz	400SE (W 140)	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	-	-	-	-	-	24"
1992	1992	Mercedes-Benz	400SE (W 140)	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1973	1980	Mercedes-Benz	450SE, SEL	-	Driver Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1973	1980	Mercedes-Benz	450SE, SEL	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1976	1980	Mercedes-Benz	450SL, SLC	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1973	1975	Mercedes-Benz	450SL, SLC	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1993	Mercedes-Benz	500E (W 124)	-	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1992	1993	Mercedes-Benz	500SEC, SEL (W 140)	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	-	-	-	-	-	24"
1992	1993	Mercedes-Benz	500SEC, SEL (W 140)	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1990	1993	Mercedes-Benz	500SL (R129)	Convertible	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1986	1989	Mercedes-Benz	560SL (W 107)	Convertible	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1993	Mercedes-Benz	600SEL (W 140)	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	-	-	-	-	-	24"
1992	1993	Mercedes-Benz	600SEL (W 140)	-	Passenger Side	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1993	1993	Mercedes-Benz	600SEC, SL (R129)	-	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2014	2014	Mercedes-Benz	A-Class (A180, A200, A250, A45 AMG)	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2016	2017	Mercedes-Benz	B-Class	-	Driver Side	Beam	I&L	97065	E	-		-			26"
2016	2017	Mercedes-Benz	B-Class	-	Passenger Side	Beam	I&L	97048	E						19"
2013	2015	Mercedes-Benz	B-Class (B180, B250)	inc Electric Drive	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2013	2015	Mercedes-Benz	B-Class (B180, B250)	inc Electric Drive	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2014	2014	Mercedes-Benz	A-Class (A180, A200, A250, A45 AMG)	-	Passenger Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2011	2012	Mercedes-Benz	B-Class (B180, B200)	Canada	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2011	2012	Mercedes-Benz	B-Class (B180, B200)	Canada	Passenger Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2006	2010	Mercedes-Benz	B-Class (B200)	Canada	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2006	2010	Mercedes-Benz	B-Class (B200)	Canada	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2015	2017	Mercedes-Benz	C-Class	-	Driver Side	Beam	I&L								"
2015	2017	Mercedes-Benz	C-Class	-	Passenger Side	Beam	I&L								"
2010	2014	Mercedes-Benz	C-Class (C180, C250, C280, C300, C350, C63 AMG)	(W204)	Front	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2008	2009	Mercedes-Benz	C-Class (C180, C250, C280, C300, C350, C63 AMG)	(W204)	Front	Beam	Narrow Pin & Hook	97060	A	-	-	-	-	-	24"
2004	2007	Mercedes-Benz	C-Class Wagon (C240, C320)	(W203)	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2001	2003	Mercedes-Benz	C-Class (C200, C230, C240, C32 AMG, C320)	(W203)	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C2	-	-	-	24"
2001	2003	Mercedes-Benz	C-Class (C200, C230, C240, C32 AMG, C320)	(W203)	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C2	-	-	-	22"
2001	2003	Mercedes-Benz	C-Class Wagon (C240, C320)	(W203)	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1994	2000	Mercedes-Benz	C-Class (C220, C230, C280, C36 AMG, C43 AMG)	(W202)	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	2000	Mercedes-Benz	C-Class	(W202)	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2017	Mercedes-Benz	CLA-Class	CLA200, CLA250, CLA45 AMG	Driver Side	Beam	MB	97060	E	-	-	-	-	-	24"
2016	2017	Mercedes-Benz	CLA-Class	CLA200, CLA250, CLA45 AMG	Passenger Side	Beam	MB	97048	E	-	-	-	-	-	19"
2007	2014	Mercedes-Benz	CL-Class (CL500, CL550, CL600 CL63 AMG, CL65 AMG)	-	Front	Beam	Pin & Hook	97070	B	-	-	-	-	-	28"
2001	2006	Mercedes-Benz	CL-Class (CL200, CL230, CL500, CL55 AMG, CL600, CL65 AMG)	-	Front	Beam	Pin & Hook	97070	B	-	-	-	-	-	28"
2014	2015	Mercedes-Benz	CLA (CLA200, CLA250, CLA45 AMG)	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2014	2015	Mercedes-Benz	CLA (CLA200, CLA250, CLA45 AMG)	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
1998	2003	Mercedes-Benz	CLK-Class (320, 430, 500, 55 AMG)	(C208)	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2018	2018	Mercedes-Benz	AMG	GT, GTC, GTR, GTS	Driver Side	Conv	Pin & Hook	97050	B	-	-	-	-	-	20"
2018	2018	Mercedes-Benz	AMG	GT, GTC, GTR, GTS	Passenger Side	Conv	Pin & Hook	97050	B	-	-	-	-	-	20"
2018	2018	Mercedes-Benz	CLA	250	Driver Side	Conv	Pin & Hook	97060	B	-	-	-	-	-	24"
2018	2018	Mercedes-Benz	CLA	250	Passenger Side	Conv	Pin & Hook	97048	B	-	-	-	-	-	19"
2016	2018	Mercedes-Benz	CLS	400	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2012	2015	Mercedes-Benz	CLS-Class (350, 500, 550, 63 AMG)	-	Front	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2005	2011	Mercedes-Benz	CLS-Class (350, 500, 55 AMG, 550, 63AMG)	-	Front	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2016	2017	Mercedes-Benz	E- Class	-	Driver Side	Beam	MB	97060	E	-	-	-	-	-	24"
2016	2017	Mercedes-Benz	E- Class	-	Passenger Side	Beam	MB	97055	E	-	-	-	-	-	22"
2010	2015	Mercedes-Benz	E-Class (200, 250, 300, 350, 400, 500, 550, 63 AMG/S)	(W212) Inc Coupe, Cabriolet, Hybrid, Wagon	Front	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2003	2009	Mercedes-Benz	E-Class (280, 320, 350, 500, 55 AMG, 550, 63 AMG)	(W211)	Front	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2003	2009	Mercedes-Benz	E-Class	(W211)	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1996	2002	Mercedes-Benz	E-Class (280, 300, 320, 420, 430, 500, 55AMG)	(W210)	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1998	2002	Mercedes-Benz	E-Class Wagon (E320)	(W210)	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1994	1995	Mercedes-Benz	E-Class (300, 320, 420)	(W124)	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1994	1995	Mercedes-Benz	E-Class Wagon (320)	(W124)	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2016	2018	Mercedes-Benz	CLS	400	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2002	2018	Mercedes-Benz	G-Class (500, 55 AMG, 550, G63)	-	Driver Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2018	Mercedes-Benz	G-Class (500, 55 AMG, 550, G63)	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2017	2017	Mercedes-Benz	GLA45 AMG	-	Driver Side	Beam	MB	97060	E	-	-	-	-	-	24"
2017	2017	Mercedes-Benz	GLA45 AMG	-	Passenger Side	Beam	MB	97048	E	-	-	-	-	-	19"
2017	2017	Mercedes-Benz	GLC 300	-	Driver Side	Beam	MB	97055	E	-	-	-	-	-	22"
2017	2017	Mercedes-Benz	GLC 300	-	Passenger Side	Beam	MB	97055	E	-	-	-	-	-	22"
2017	2017	Mercedes-Benz	GLC 43 AMG	-	Driver Side	Beam	MB	97055	E	-	-	-	-	-	22"
2017	2017	Mercedes-Benz	GLC 43 AMG	-	Passenger Side	Beam	MB	97055	E	-	-	-	-	-	22"
2016	2016	Mercedes-Benz	GLC	-	Driver Side	Beam	MB	97055	E	-	-	-	-	-	22"
2016	2016	Mercedes-Benz	GLC	-	Passenger Side	Beam	MB	97055	E	-	-	-	-	-	22"
2013	2015	Mercedes-Benz	GL-Class (350, 450, 500, 550, 63 AMG)	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2013	2015	Mercedes-Benz	GL-Class (350, 450, 500, 550, 63 AMG)	-	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2007	2012	Mercedes-Benz	GL-Class (320, 350, 450, 500, 550	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2007	2012	Mercedes-Benz	GL-Class (320, 350, 450, 500, 550	-	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2015	2018	Mercedes-Benz	GLA (GLA240, GLA45AMG)	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2015	2018	Mercedes-Benz	GLA (GLA240, GLA45AMG)	-	Passenger Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2018	2018	Mercedes-Benz	GLC300	-	Driver Side	Beam	Narrow PTB	97055	B	-	-	-	-	-	22"
2018	2018	Mercedes-Benz	GLC300	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2016	2018	Mercedes-Benz	GLE Class	450, 43 AMG, 550E, 63 AMG, 63AMG S	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2016	2018	Mercedes-Benz	GLE Class	450, 43 AMG, 550E, 63 AMG, 63AMG S	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2015	2015	Mercedes-Benz	GLK (250, 280, 300, 350)	-	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2015	2015	Mercedes-Benz	GLK (250, 280, 300, 350)	-	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
2009	2014	Mercedes-Benz	GLK (250, 280, 300, 350)	-	Driver Side	Beam	Pin & Hook	97055	B	-	-	-	-	-	22"
2009	2014	Mercedes-Benz	GLK (250, 280, 300, 350)	-	Passenger Side	Beam	Pin & Hook	97048	B	-	-	-	-	-	19"
2016	2018	Mercedes-Benz	GLS 550	-	Driver Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2016	2018	Mercedes-Benz	GLS 550	-	Passenger Side	Beam	PTB	97040	A	-	-	-	-	-	16"
2016	2016	Mercedes-Benz	GTS	-	Driver Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2016	2016	Mercedes-Benz	GTS	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2012	2015	Mercedes-Benz	ML-Class (350, 500, 550, 63 AMG)	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2012	2015	Mercedes-Benz	ML-Class (350, 500, 550, 63 AMG)	-	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2006	2011	Mercedes-Benz	ML-Class (320, 350, 450, 500, 550, 63 AMG)	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2006	2011	Mercedes-Benz	ML-Class (320, 350, 450, 500, 550, 63 AMG)	-	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2000	2005	Mercedes-Benz	ML-Class (320, 350, 430, 500, 55 AMG)	-	Front	Conv	Hook slot 9x4	97055	V	95055	C2	-	-	-	22"
2000	2005	Mercedes-Benz	ML-Class (320, 350, 430, 500, 55 AMG)	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	-	-	-	17"
1998	1999	Mercedes-Benz	M-Class (ML)	-	Front	Conv	Hook slot 9x4	97055	V	95055	C2	-	-	-	22"
1998	1999	Mercedes-Benz	M-Class (ML)	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	-	-	-	16"
2006	2013	Mercedes-Benz	R-Class (320, 350, 500, 63 AMG)	-	Driver Side	Beam	I&L	97070	A	-	-	-	-	-	28"
2006	2013	Mercedes-Benz	R-Class (320, 350, 500, 63 AMG)	-	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2006	2013	Mercedes-Benz	S-Class (350, 400, 430, 450, 500, 550, 55 AMG, 600, 63 AMG, 65 AMG)	-	Front	Beam	Pin & Hook	97070	B	-	-	-	-	-	28"
1994	1998	Mercedes-Benz	S-Class	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2018	2018	Mercedes-Benz	Maybach S650	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2018	2018	Mercedes-Benz	Maybach S650	-	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2018	2018	Mercedes-Benz	Maybach S450	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2018	2018	Mercedes-Benz	Maybach S450	-	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2018	2018	Mercedes-Benz	S63 AMG	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2018	2018	Mercedes-Benz	S63 AMG	-	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2018	2018	Mercedes-Benz	S65 AMG	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2018	2018	Mercedes-Benz	S65 AMG	-	Passenger Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2018	2018	Mercedes-Benz	SL500	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2018	2018	Mercedes-Benz	SL500	-	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2018	2018	Mercedes-Benz	SL65 AMG	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2018	2018	Mercedes-Benz	SL65 AMG	-	Passenger Side	Beam	PTB	97055	A	-	-	-	-	-	22"
2016	2018	Mercedes-Benz	SLC-Class	300, 43 AMG	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2016	2018	Mercedes-Benz	SLC-Class	300, 43 AMG	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2002	2011	Mercedes-Benz	SL-Class (500, 55 AMG, 550, 600, 63 AMG, 65 AMG)	-	Front	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
1994	2001	Mercedes-Benz	SL-Class (320, 500, 60 AMG, 600)	(R129)	Front (Single Blade)	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"

PIAA

YEAR (Range) Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	SI-TECH WIPER PN	SI-TECH ADAPTER	SUPER SILICONE	SUPER SILICONE	AERO VOGUE	AERO VOGUE ADAPTER	NOTES	LENGTH
2005	2015	Mercedes-Benz	SLK-Class (200, 250, 280, 300, 350, 55 AMG)	(R171)	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2005	2015	Mercedes-Benz	SLK-Class (200, 250, 280, 300, 350, 55 AMG)	(R171)	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
1997	2004	Mercedes-Benz	SLK-Class (200, 230, 32 AMG, 320)	(R170)	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C2	-	-	-	22"
1997	2004	Mercedes-Benz	SLK-Class (200, 230, 32 AMG, 320)	(R170)	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C2	-	-	-	22"
2005	2009	Mercedes-Benz	SLR McLaren	(R199)	Front	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2013	2014	Mercedes-Benz	SLS AMG	Coupe & Roadster	Front	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2011	2012	Mercedes-Benz	SLS AMG	-	Driver Side	Beam	Pin & Hook	97053	B	-	-	-	-	-	21"
2011	2012	Mercedes-Benz	SLS AMG	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2010	2014	Mercedes-Benz	Sprinter	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2010	2014	Mercedes-Benz	Sprinter	-	Passenger Side	Beam	I&L	97060	A	-	-	-	-	-	24"
1979	1980	Mercury	Bobcat	-	Front Left	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1983	1986	Mercury	Capri	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1979	1982	Mercury	Capri	-	Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1999	2002	Mercury	Cougar	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2002	Mercury	Cougar	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1999	2002	Mercury	Cougar	-	Rear	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1997	Mercury	Cougar	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1989	1989	Mercury	Cougar	-	Driver Side	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1989	1989	Mercury	Cougar	-	Passenger Side	Conv	Pin Arm	97050	V	-	-	-	-	-	20"
1983	1988	Mercury	Cougar	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1974	1982	Mercury	Cougar	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1994	2011	Mercury	Grand Marquis	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1993	1993	Mercury	Grand Marquis	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1975	1990	Mercury	Grand Marquis	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1982	1983	Mercury	LN7	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1981	1987	Mercury	Lynx	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2003	2004	Mercury	Marauder	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
2008	2011	Mercury	Mariner	-	Front	Beam	I&L	97050	A	-	-	-	-	-	20"
2005	2007	Mercury	Mariner	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2007	Mercury	Mariner	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1984	1986	Mercury	Marquis	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1983	Mercury	Marquis	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1985	Mercury	Marquis	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2006	2011	Mercury	Milan	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2011	Mercury	Milan	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1975	1980	Mercury	Monarch	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2007	2007	Mercury	Montego	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2007	2007	Mercury	Montego	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2005	2006	Mercury	Montego	-	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2005	2006	Mercury	Montego	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
1970	1976	Mercury	Montego	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2004	2007	Mercury	Monterey	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2004	2007	Mercury	Monterey	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2004	2007	Mercury	Monterey	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1971	1974	Mercury	Monterey	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2006	2010	Mercury	Mountaineer	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2005	Mercury	Mountaineer	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2005	Mercury	Mountaineer	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2004	Mercury	Mountaineer	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2004	Mercury	Mountaineer	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1998	2001	Mercury	Mountaineer	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	2000	Mercury	Mystique	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	2000	Mercury	Mystique	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2009	2009	Mercury	Sable	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2009	2009	Mercury	Sable	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2008	2008	Mercury	Sable	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2008	2008	Mercury	Sable	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
1996	2005	Mercury	Sable	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1996	2005	Mercury	Sable	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	2005	Mercury	Sable	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1995	Mercury	Sable	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1986	1988	Mercury	Sable	-	Front	Conv	Pin Arm 1/4"	97050	V	-	-	-	-	-	20"
1986	1994	Mercury	Topaz	-	Front	Conv	Pin Arm 3/16"	97050	V	-	-	-	-	-	20"
1985	1985	Mercury	Topaz	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1984	1984	Mercury	Topaz	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1991	1999	Mercury	Tracer	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1999	Mercury	Tracer	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1999	2002	Mercury	Villager	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1978	1983	Mercury	Zephyr	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2016	2018	Mini	Cooper Clubman	-	Driver Side	Beam	Narrow PTB	97055	B	-	-	-	-	-	22"
2016	2018	Mini	Cooper Clubman	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2013	2014	Mini	Cooper Clubman	Incl. S / S Clubman Hampton / JC Works	Driver Side	Beam	GEN2D | Bayonet	97045	C	-	-	-	-	-	18"
2013	2014	Mini	Cooper Clubman	Incl. S / S Clubman Hampton / JC Works	Passenger Side	Beam	GEN2D | Bayonet	97048	C	-	-	-	-	-	19"
2012	2015	Mini	Cooper Coupe / Roadster	Inc. S & JC Works	Driver Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2012	2015	Mini	Cooper Coupe / Roadster	Inc. S & JC Works	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2011	2016	Mini	Cooper Countryman	Inc. S & JC Works	Driver Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2011	2016	Mini	Cooper Countryman	Inc. S & JC Works	Passenger Side	Beam	I&L	97053	A	-	-	-	-	-	21"
2014	2018	Mini	Cooper Hardtop (Hatchback) / Convertible	Inc S	Driver Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2014	2018	Mini	Cooper Hardtop (Hatchback) / Convertible	Inc S	Passenger Side	Hybrid	Hook	97048	V	-	-	-	-	-	19"
2002	2013	Mini	Cooper Hardtop (Hatchback) / Convertible	Inc S	Driver Side	Beam	Hook	97045	V	-	-	-	-	-	18"
2002	2013	Mini	Cooper Hardtop (Hatchback) / Convertible	Inc S	Passenger Side	Beam	Hook	97048	V	-	-	-	-	-	19"
2013	2016	Mini	Cooper Paceman	Inc. S & JC Works	Driver Side	Beam	I&L	97048	A	-	-	-	-	-	19"
2013	2016	Mini	Cooper Paceman	Inc. S & JC Works	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
1991	1999	Mitsubishi	3000 GT	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1991	1999	Mitsubishi	3000 GT	-	Front Right	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	2005	Mitsubishi	Diamante	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	2005	Mitsubishi	Diamante	-	Front Right	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1996	Mitsubishi	Diamante	-	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1996	Mitsubishi	Diamante	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1993	1995	Mitsubishi	Diamante	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2006	2012	Mitsubishi	Eclipse	Inc. Spyder	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2012	Mitsubishi	Eclipse	Inc. Spyder	Front Right	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2012	Mitsubishi	Eclipse	Inc. Spyder	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2000	2005	Mitsubishi	Eclipse	Inc. Spyder	Front Left	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2000	2005	Mitsubishi	Eclipse	Inc. Spyder	Front Right	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2000	2005	Mitsubishi	Eclipse	Inc. Spyder	Rear	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1999	Mitsubishi	Eclipse	Inc. Spyder	Front Left	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1995	1999	Mitsubishi	Eclipse	Inc. Spyder	Front Right	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	1999	Mitsubishi	Eclipse	Inc. Spyder	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	1996	Mitsubishi	Eclipse	Inc. Spyder	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1994	Mitsubishi	Eclipse	Inc. Spyder	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2010	2011	Mitsubishi	Endeavor	-	Front Left	Conv	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2010	2011	Mitsubishi	Endeavor	-	Front Right	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2004	2008	Mitsubishi	Endeavor	-	Front Left	Conv	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2004	2008	Mitsubishi	Endeavor	-	Front Right	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1995	Mitsubishi	Expo LRV Wagon	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1995	Mitsubishi	Expo LRV Wagon	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1995	Mitsubishi	Expo LRV Wagon	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2004	2012	Mitsubishi	Galant	-	Front Left	Conv	Hook slot 9x4	97065	V	95065	C3	-	-	-	26"
2004	2012	Mitsubishi	Galant	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2003	Mitsubishi	Galant	-	Front Left	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2003	Mitsubishi	Galant	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1998	Mitsubishi	Galant	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1994	1998	Mitsubishi	Galant	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1989	1993	Mitsubishi	Galant	-	Front Left	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1989	1993	Mitsubishi	Galant	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2012	2014	Mitsubishi	i-MiEV	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2012	2014	Mitsubishi	i-MiEV	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2017	2018	Mitsubishi	Mirage	Incl. G4	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2017	2018	Mitsubishi	Mirage	Incl. G4	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2008	2016	Mitsubishi	Lancer	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2016	Mitsubishi	Lancer	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2010	2015	Mitsubishi	Lancer	-	Rear	Conv	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2004	2006	Mitsubishi	Lancer	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2004	2006	Mitsubishi	Lancer	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2002	2003	Mitsubishi	Lancer	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2003	Mitsubishi	Lancer	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2002	2004	Mitsubishi	Lancer	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2008	2012	Mitsubishi	Lancer Evolution	-	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2012	Mitsubishi	Lancer Evolution	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2006	Mitsubishi	Lancer Evolution	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2006	Mitsubishi	Lancer Evolution	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2006	Mitsubishi	Lancer Evolution	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2014	2015	Mitsubishi	Mirage	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2014	2015	Mitsubishi	Mirage	-	Passenger Side	Conv	Hook slot 9x3/9x4	97040	V	95040	C1	96140	Locking Clip	-	16"
1997	2002	Mitsubishi	Mirage	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1997	2002	Mitsubishi	Mirage	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1993	1996	Mitsubishi	Mirage	-	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1996	Mitsubishi	Mirage	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1992	Mitsubishi	Mirage	-	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1992	Mitsubishi	Mirage	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2001	2006	Mitsubishi	Montero	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"

PIAA

YEAR (Range)								SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2001	2006	Mitsubishi	Montero	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	2000	Mitsubishi	Montero	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1997	2005	Mitsubishi	Montero Sport	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	2005	Mitsubishi	Montero Sport	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2014	2018	Mitsubishi	Outlander	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2014	2018	Mitsubishi	Outlander	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2010	2013	Mitsubishi	Outlander	-	Front Left	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2013	Mitsubishi	Outlander	-	Front Right	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2009	Mitsubishi	Outlander	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2009	Mitsubishi	Outlander	-	Front Right	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2003	2006	Mitsubishi	Outlander	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2006	Mitsubishi	Outlander	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2015	Mitsubishi	Outlander Sport	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2015	Mitsubishi	Outlander Sport	-	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1990	1994	Mitsubishi	Precis	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1990	1994	Mitsubishi	Precis	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1987	1989	Mitsubishi	Precis	-	Front & Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2006	2009	Mitsubishi	Raider	-	Front	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1998	1998	Nissan	200SX	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1998	1998	Nissan	200SX	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	1997	Nissan	200SX	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1997	Nissan	200SX	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1984	1988	Nissan	200SX	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	1998	Nissan	240SX	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1998	Nissan	240SX	-	Front Right	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1994	Nissan	240SX	-	Front & Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1990	1996	Nissan	300ZX	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1996	Nissan	300ZX	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1990	1994	Nissan	300ZX	-	Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1987	1989	Nissan	300ZX	-	Front & Rear	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1986	Nissan	300ZX	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2003	2009	Nissan	350Z	-	Front Left	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2009	Nissan	350Z	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2003	2009	Nissan	350Z	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2018	Nissan	370Z	Coupe & Roadster	Front Left	Hybrid	Hook 9x3	97053	V	-	-	96153	Need 94005	Side Mount Hook	21"
2009	2018	Nissan	370Z	Coupe & Roadster	Front Right	Hybrid	Hook 9x3	97048	V	-	-	96148	Need 94005	Side Mount Hook	19"
2013	2018	Nissan	Altima	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2013	2018	Nissan	Altima	-	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Locking Clip	-	16"
2007	2012	Nissan	Altima	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Need 94005	Side Mount Hook	28"
2007	2012	Nissan	Altima	-	Passenger Side	Hybrid	Hook 9x3	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2002	2006	Nissan	Altima	-	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2002	2006	Nissan	Altima	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1993	2001	Nissan	Altima	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1993	2001	Nissan	Altima	-	Front Right	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2008	2011	Nissan	Altima Coupe	-	Front Left	Conv	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2008	2011	Nissan	Altima Coupe	-	Front Right	Conv	Hook 9x3	97043	V	-	-	-	-	-	17"
2001	2007	Nissan	Aprio	-	Front	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2017	2018	Nissan	Armada	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	-	96160	Locking Clip	-	24"
2017	2018	Nissan	Armada	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	-	96148	Locking Clip	-	19"
2004	2015	Nissan	Armada	Pathfinder Armada '04	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2004	2015	Nissan	Armada	Pathfinder Armada '04	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1992	Nissan	Axxess Van	-	Front Right	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1992	Nissan	Axxess Van	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2001	2007	Nissan	Camiones	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2014	Nissan	Cube	-	Driver Side	Conv	Hook	97050	V	-	-	-	-	-	20"
2009	2014	Nissan	Cube	-	Passenger Side	Conv	Hook	97050	V	-	-	-	-	-	20"
2005	2018	Nissan	Frontier	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2018	Nissan	Frontier	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2002	2004	Nissan	Frontier	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1998	2001	Nissan	Frontier	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2016	2018	Nissan	GT-R	-	Driver Side	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2018	Nissan	GT-R	-	Passenger Side	Beam	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2009	2015	Nissan	GT-R	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2015	Nissan	GT-R	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2017	Nissan	Juke	-	Driver Side	Conv	Hook slot 9x4 long	97055	V	-	-	-	-	-	22"
2011	2017	Nissan	Juke	-	Passenger Side	Conv	Hook slot 9x4 short	97035	V	-	-	-	-	-	14"
2018	2018	Nissan	kicks	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2018	2018	Nissan	kicks	-	Passenger Side	Hybrid	Hook 9x3	97038	V	-	-	96140	Need 94005	Side Mount Hook	14"
2011	2018	Nissan	Leaf	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2011	2018	Nissan	Leaf	-	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2016	2018	Nissan	Maxima	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Need 94005	Side Mount Hook	28"
2016	2018	Nissan	Maxima	-	Passenger Side	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2009	2015	Nissan	Maxima	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Need 94005	Side Mount Hook	28"
2009	2015	Nissan	Maxima	-	Passenger Side	Hybrid	Hook 9x3	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2000	2008	Nissan	Maxima	-	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2000	2008	Nissan	Maxima	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1995	1999	Nissan	Maxima	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1999	Nissan	Maxima	-	Front Right	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1989	1994	Nissan	Maxima	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1989	1994	Nissan	Maxima	-	Front Right	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1985	1988	Nissan	Maxima	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2001	2007	Nissan	Micra	-	Front Left	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2001	2007	Nissan	Micra	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1986	1988	Nissan	Multi Van	Canada	Front & Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2018	2018	Nissan	Micra	-	Driver Side	Hybrid	Hook 9x4	96060	V	-	-	96160	Need 94005	Side Mount Hook	24"
2018	2018	Nissan	Micra	-	Passenger Side	Hybrid	Hook 9x4	97038	V	-	-	96140	Need 94005	Side Mount Hook	14"
2015	2018	Nissan	Murano	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2015	2018	Nissan	Murano	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2014	Nissan	Murano	Inc. CrossCabriolet	Front Left	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2009	2014	Nissan	Murano	Inc. CrossCabriolet	Front Right	Hybrid	Hook 9x3	97040	V	-	-	96140	Need 94005	Side Mount Hook	16"
2006	2008	Nissan	Murano	-	Front Left	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2006	2008	Nissan	Murano	-	Front Right	Hybrid	Hook 9x3	97045	V	-	-	96145	Need 94005	Side Mount Hook	18"
2003	2005	Nissan	Murano	-	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2003	2005	Nissan	Murano	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2012	2018	Nissan	NV	1500, 2500, 3500	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1991	1993	Nissan	NX 1600, 2000	-	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1993	Nissan	NX 1600, 2000	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1993	Nissan	NX 1600, 2000	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2012	2018	Nissan	NV	1500, 2500, 3500	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2013	2018	Nissan	Pathfinder	Inc. Hybrid	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2013	2018	Nissan	Pathfinder	Inc. Hybrid	Passenger Side	Hybrid	Hook 9x3	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2005	2012	Nissan	Pathfinder	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2012	Nissan	Pathfinder	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1996	2004	Nissan	Pathfinder	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1996	2004	Nissan	Pathfinder	-	Front Right	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1987	1995	Nissan	Pathfinder	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1997	Nissan	Pickup	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1980	1986	Nissan	Pickup 720	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2007	2008	Nissan	Platina	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2008	Nissan	Platina	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1987	1990	Nissan	Pulsar NX	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1986	1986	Nissan	Pulsar	-	Front Left	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1986	Nissan	Pulsar	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2011	2017	Nissan	Quest	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2011	2017	Nissan	Quest	-	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2004	2010	Nissan	Quest	-	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2004	2010	Nissan	Quest	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	2003	Nissan	Quest	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	Nissan	Rogue	-	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	96165	Need 94005	Side Mount Hook	26"
2014	2018	Nissan	Rogue	-	Passenger Side	Hybrid	Hook 9x3	97043	V	-	-	96143	Need 94005	Side Mount Hook	17"
2008	2013	Nissan	Rogue	-	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2013	Nissan	Rogue	-	Front Right	Conv	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2016	2018	Nissan	Sentra	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2016	2018	Nissan	Sentra	-	Passenger Side	Hybrid	Hook 9x3	97038	V	-	-	96138	Locking Clip	-	15"
2013	2015	Nissan	Sentra	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Need 94005	Side Mount Hook	28"
2013	2015	Nissan	Sentra	-	Passenger Side	Hybrid	Hook 9x3	97038	V	-	-	96138	Need 94005	Side Mount Hook	15"
2007	2012	Nissan	Sentra	Inc. SE-R	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2007	2012	Nissan	Sentra	Inc. SE-R	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2003	2006	Nissan	Sentra	Inc. SE-R	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2006	Nissan	Sentra	Inc. SE-R	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2000	2002	Nissan	Sentra	Inc. SE-R	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2002	Nissan	Sentra	Inc. SE-R	Front Right	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1995	1999	Nissan	Sentra	Inc. SE-R	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1999	Nissan	Sentra	Inc. SE-R	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1991	1994	Nissan	Sentra	Inc. SE-R	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1994	Nissan	Sentra	Inc. SE-R	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1987	1990	Nissan	Sentra	Inc. SE-R	Front Left	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1987	1990	Nissan	Sentra	Inc. SE-R	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1985	1986	Nissan	Sentra	Inc. SE-R	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1990	1992	Nissan	Stanza	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1987	1989	Nissan	Stanza	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1989	Nissan	Stanza Wagon	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1989	Nissan	Stanza Wagon	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Nissan	Titan	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2016	2018	Nissan	Titan	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2004	2015	Nissan	Titan	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2004	2015	Nissan	Titan	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2008	Nissan	Tsuru	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2007	Nissan	Urvan	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2007	2018	Nissan	Versa	-	Front Left	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"

PIAA

YEAR (Range)									SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2007	2018	Nissan	Versa	-	Front Right	Conv	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
2014	2018	Nissan	Versa Note	-	Front Left	Hybrid	Hook 9x3	97070	V	-	-	96170	Need 94005	Side Mount Hook	28"
1987	1988	Nissan	XE Van	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1987	1988	Nissan	XE Van	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2015	Nissan	Xterra	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2015	Nissan	Xterra	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2000	2004	Nissan	Xterra	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2001	2009	Nissan	X-Trail	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2005	2006	Nissan	X-Trail	Canada	Front Left	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2006	Nissan	X-Trail	Canada	Front Right	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2001	2007	Nissan	X-Trail	Canada	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2005	2008	Nissan	Z / Z Roadster	-	Front Left	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2008	Nissan	Z / Z Roadster	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2008	Nissan	Z / Z Roadster	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1998	Oldsmobile	98 Regency	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1985	1990	Oldsmobile	98 Regency	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1968	1984	Oldsmobile	98 Regency	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1992	1998	Oldsmobile	Achieva	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1998	2004	Oldsmobile	Alero	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1998	2004	Oldsmobile	Alero	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2001	2003	Oldsmobile	Aurora	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	1999	Oldsmobile	Aurora	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
2001	2004	Oldsmobile	Bravada	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2004	Oldsmobile	Bravada	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1996	2000	Oldsmobile	Bravada	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1991	1994	Oldsmobile	Bravada	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1991	1992	Oldsmobile	Custom Cruiser Wagon	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1991	1992	Oldsmobile	Custom Cruiser Wagon	-	Rear	Conv	Pin Arm	97043	V	-	-	-	-	-	17"
1971	1990	Oldsmobile	Custom Cruiser Wagon	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1990	Oldsmobile	Custom Cruiser Wagon	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1997	1999	Oldsmobile	Cutlass	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	1999	Oldsmobile	Cutlass	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1985	1991	Oldsmobile	Cutlass Calais	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1984	1996	Oldsmobile	Cutlass Ciera	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1978	1983	Oldsmobile	Cutlass Cruiser	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1978	1983	Oldsmobile	Cutlass Cruiser	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1988	1997	Oldsmobile	Cutlass Supreme	-	Front	Conv	Pin Arm	97050	V	-	-	-	-	-	20"
1978	1988	Oldsmobile	Cutlass Supreme	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Oldsmobile	Cutlass Supreme	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1968	1972	Oldsmobile	Cutlass Supreme	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1992	1999	Oldsmobile	Delta 88	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1986	1991	Oldsmobile	Delta 88	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1968	1985	Oldsmobile	Delta 88	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1968	1972	Oldsmobile	F-85	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1983	1988	Oldsmobile	Firenza	-	Front & Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1988	Oldsmobile	Firenza	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1986	1987	Oldsmobile	Firenza	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1998	2003	Oldsmobile	Intrigue	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1996	1998	Oldsmobile	LS, LSS	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1980	1984	Oldsmobile	Omega	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1979	Oldsmobile	Omega	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1997	2004	Oldsmobile	Silhouette	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	2004	Oldsmobile	Silhouette	-	Front Right	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	2004	Oldsmobile	Silhouette	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1986	1992	Oldsmobile	Toronado	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1971	1985	Oldsmobile	Toronado	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1988	1992	Oldsmobile	Trofeo	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1973	1977	Oldsmobile	Vista Cruiser	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1981	1991	Peugeot	505	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1979	1984	Peugeot	604	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1995	Plymouth	Acclaim	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1974	Plymouth	Barracuda	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1996	2000	Plymouth	Breeze	-	Front Left	Conv	Hook slot 9x4	97055	V	95055	C4	-	-	-	22"
1996	2000	Plymouth	Breeze	-	Front Right	Conv	Hook slot 9x4	97055	V	95055	C4	-	-	-	22"
1983	1989	Plymouth	Caraveile	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1989	1994	Plymouth	Colt	-	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1994	Plymouth	Colt	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1992	1994	Plymouth	Colt Wagon, Vista Wagon	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1994	Plymouth	Colt Wagon, Vista Wagon	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1992	1994	Plymouth	Colt Wagon, Vista Wagon	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1974	1989	Plymouth	Fury, Grand Fury	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1969	1973	Plymouth	Fury, Grand Fury	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1992	1994	Plymouth	Laser	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2001	Plymouth	Neon	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2001	Plymouth	Neon	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1994	1999	Plymouth	Neon	-	Front Left	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1994	1999	Plymouth	Neon	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	2002	Plymouth	Prowler	-	Front Left	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1997	2002	Plymouth	Prowler	-	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1981	1989	Plymouth	Reliant	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1975	1975	Plymouth	Roadrunner	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1974	Plymouth	Roadrunner	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1971	1974	Plymouth	Satellite	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1987	1994	Plymouth	Sundance	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1980	1980	Plymouth	Volare	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1996	2000	Plymouth	Voyager, Grand Voyager	-	Front Left	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1996	2000	Plymouth	Voyager, Grand Voyager	-	Front Right	Conv	Hook slot 9x4	97070	V	-	-	-	-	-	28"
1996	2000	Plymouth	Voyager, Grand Voyager	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1995	1995	Plymouth	Voyager, Grand Voyager	-	Front	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1995	Plymouth	Voyager, Grand Voyager	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1994	Plymouth	Voyager, Grand Voyager	-	Front Left	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	1994	Plymouth	Voyager, Grand Voyager	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1994	1994	Plymouth	Voyager, Grand Voyager	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1991	1993	Plymouth	Voyager, Grand Voyager	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1991	1993	Plymouth	Voyager, Grand Voyager	-	Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1990	Plymouth	Voyager, Grand Voyager	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1990	Plymouth	Voyager, Grand Voyager	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1974	1983	Plymouth	Voyager, Grand Voyager	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1983	1987	Pontiac	1000	-	Front & Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1983	1984	Pontiac	2000	-	Front & Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1984	1991	Pontiac	6000	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1991	Pontiac	6000	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1987	Pontiac	Acadian	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1987	Pontiac	Acadian	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1976	1981	Pontiac	Acadian	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2001	2005	Pontiac	Aztek	-	Front Left	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2001	2005	Pontiac	Aztek	-	Front Right	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2000	2005	Pontiac	Bonneville	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1999	Pontiac	Bonneville	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1987	1991	Pontiac	Bonneville	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1971	1986	Pontiac	Bonneville	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1981	Pontiac	Catalina	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1970	Pontiac	Catalina	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1970	1970	Pontiac	Executive	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1988	Pontiac	Fiero	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1998	2002	Pontiac	Firebird / Trans Am	-	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1982	1992	Pontiac	Firebird / Trans Am	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1981	Pontiac	Firebird / Trans Am	70-76 fitment note: with single arm	Front Left	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1970	1976	Pontiac	Firebird / Trans Am	70-76 fitment note: with double arm	Front Left	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1995	2001	Pontiac	Firefly	Canada	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1995	2001	Pontiac	Firefly	Canada	Front Right	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1989	1994	Pontiac	Firefly	Canada	Front Left	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1994	Pontiac	Firefly	Canada	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1994	Pontiac	Firefly	Canada	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1985	1988	Pontiac	Firefly	Canada	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1985	1988	Pontiac	Firefly	Canada	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2009	2010	Pontiac	G3	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2010	Pontiac	G3	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2010	Pontiac	G5	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2010	Pontiac	G5	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2009	2010	Pontiac	G6	-	Front Left	Beam	I&L	97060	A	-	-	-	-	-	24"
2009	2010	Pontiac	G6	-	Front Right	Beam	I&L	97053	A	-	-	-	-	-	21"
2008	2008	Pontiac	G6	-	Front Left	Beam	PTB	97060	A	-	-	-	-	-	24"
2008	2008	Pontiac	G6	-	Front Right	Beam	PTB	97053	A	-	-	-	-	-	21"
2005	2007	Pontiac	G6	-	Front Left	Beam	I&L	97060	A	-	-	-	-	-	24"
2005	2007	Pontiac	G6	-	Front Right	Beam	I&L	97053	A	-	-	-	-	-	21"
2008	2010	Pontiac	G8	-	Front Left	Beam	I&L	97065	A	-	-	-	-	-	26"
2008	2010	Pontiac	G8	-	Front Right	Beam	I&L	97038	A	-	-	-	-	-	15"
1999	2005	Pontiac	Grand Am	Sedan & Coupe	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2005	Pontiac	Grand Am	Sedan & Coupe	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1985	1998	Pontiac	Grand Am	Sedan & Coupe	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1978	1980	Pontiac	Grand Am	Sedan & Coupe	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Pontiac	Grand Am	Sedan & Coupe	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1978	1981	Pontiac	Grand LeMans	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Pontiac	Grand LeMans	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2006	2008	Pontiac	Grand Prix	-	Front	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1997	2005	Pontiac	Grand Prix	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1988	1996	Pontiac	Grand Prix	-	Front	Conv	Pin Arm 1/4"	97050	V	-	-	-	-	-	20"
1978	1987	Pontiac	Grand Prix	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Pontiac	Grand Prix	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"

PIAA

YEAR (Range)								SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
1968	1972	Pontiac	Grand Prix	-	Front Left	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1971	1975	Pontiac	Grand Ville	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
2004	2006	Pontiac	GTO	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2006	Pontiac	GTO	-	Front Right	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1968	1972	Pontiac	GTO	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1982	1982	Pontiac	J2000	-	Front & Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1988	1993	Pontiac	LeMans	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1978	1981	Pontiac	LeMans	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Pontiac	LeMans	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1968	1972	Pontiac	LeMans	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2006	2009	Pontiac	Montana	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2009	Pontiac	Montana	-	Front Right	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2009	Pontiac	Montana	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1999	2005	Pontiac	Montana	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2005	Pontiac	Montana	-	Front Right	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2005	Pontiac	Montana	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2005	2008	Pontiac	Montana SV6	-	Front Left	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2005	2008	Pontiac	Montana SV6	-	Front Right	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2005	2008	Pontiac	Montana SV6	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1988	1993	Pontiac	Optima	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1983	1986	Pontiac	Parisienne	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1980	1984	Pontiac	Phoenix	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1977	1979	Pontiac	Phoenix	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2005	2006	Pontiac	Pursuit Canada / G5	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2006	Pontiac	Pursuit Canada / G5	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1984	1991	Pontiac	Safari Wagon	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1991	Pontiac	Safari Wagon	-	Rear	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1987	1989	Pontiac	Safari Wagon	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1978	1981	Pontiac	Safari Wagon	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1971	1981	Pontiac	Safari Wagon	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1973	1977	Pontiac	Safari Wagon	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2005	2010	Pontiac	Solstice	-	Front Left	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2005	2010	Pontiac	Solstice	-	Front Right	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1990	1994	Pontiac	Sunbird	-	Front	Conv	Pin Arm	97043	V	-	-	-	-	-	17"
1985	1989	Pontiac	Sunbird	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1985	1988	Pontiac	Sunburst	Canada	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1995	2005	Pontiac	Sunfire	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	2005	Pontiac	Sunfire	-	Front Right	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1995	1998	Pontiac	Sunrunner	Canada	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2006	2006	Pontiac	SV6	-	Front Left	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2006	2006	Pontiac	SV6	-	Front Right	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2006	2006	Pontiac	SV6	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1982	1982	Pontiac	T1000	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
1987	1992	Pontiac	Tempest	-	Front	Conv	Pin Arm	97048	V	-	-	-	-	-	19"
1968	1970	Pontiac	Tempest	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2006	2010	Pontiac	Torrent	-	Front Left	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2009	Pontiac	Torrent	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2006	2009	Pontiac	Torrent	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1997	1998	Pontiac	Trans Sport	-	Front	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1997	1998	Pontiac	Trans Sport	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1990	1996	Pontiac	Trans Sport	-	Front	Conv	Pin Arm	97055	V	-	-	-	-	-	22"
1971	1977	Pontiac	Ventura	-	Front	Conv	Pin Arm	97040	V	-	-	-	-	-	16"
2009	2010	Pontiac	Vibe	-	Front Left	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2009	2010	Pontiac	Vibe	-	Front Right	Hybrid	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2002	2008	Pontiac	Vibe	-	Front Left	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2002	2008	Pontiac	Vibe	-	Front Right	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2008	Pontiac	Wave(Canada)	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2008	Pontiac	Wave(Canada)	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2008	Pontiac	Wave	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2013	2018	Porsche	911	Inc. Carerra	Driver Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2013	2018	Porsche	911	Inc. Carerra	Passenger Side	Beam	Narrow PTB	97055	B	-	-	-	-	-	22"
2005	2012	Porsche	911	Inc. Carerra	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2005	2012	Porsche	911	Inc. Carerra	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1999	2004	Porsche	911	Inc. Carerra	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1999	2004	Porsche	911	Inc. Carerra	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1999	2004	Porsche	911	Inc. Carerra	Rear	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1995	1998	Porsche	911	Inc. Carerra	Driver Side	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1995	1998	Porsche	911	Inc. Carerra	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1985	1991	Porsche	944	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1995	Porsche	968	-	Front	Conv	Hook slot 9x4	97048	V	95048	C3	-	-	-	19"
1992	1995	Porsche	968	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2016	2018	Porsche	Boxster	Inc. S	Driver Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2016	2018	Porsche	Boxster	Inc. S	Passenger Side	Beam	Narrow PTB	97055	B	-	-	-	-	-	22"
2013	2015	Porsche	Boxster	Inc. S	Driver Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2013	2015	Porsche	Boxster	Inc. S	Passenger Side	Beam	Narrow PTB	97055	B	-	-	-	-	-	22"
2003	2012	Porsche	Boxster	Inc. S	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2003	2012	Porsche	Boxster	Inc. S	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1997	2002	Porsche	Boxster	Inc. S	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1997	2002	Porsche	Boxster	Inc. S	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2009	2018	Porsche	Cayenne	-	Front	Beam	PTB	97060	B	-	-	-	-	-	24"
2003	2008	Porsche	Cayenne	-	Front	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2003	2011	Porsche	Cayenne	-	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2014	2018	Porsche	Cayman	Inc. S	Driver Side	Beam	Narrow PTB	97053	B	-	-	-	-	-	21"
2014	2018	Porsche	Cayman	Inc. S	Passenger Side	Beam	Narrow PTB	97055	B	-	-	-	-	-	22"
2006	2012	Porsche	Cayman	Inc. S	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2006	2012	Porsche	Cayman	Inc. S	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2014	2018	Porsche	Macan	-	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2014	2018	Porsche	Macan	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2014	2016	Porsche	Panamera	-	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2014	2016	Porsche	Panamera	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2010	2013	Porsche	Panamera	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2013	Porsche	Panamera	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2013	2018	Ram	1500/2500/3500/4500/5500	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2018	Ram	2500	Laramie	Front	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2016	Ram	3500	Chassis Cab & Laramie Longhorn	Front	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2013	2015	Ram	C/V	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2015	Ram	C/V	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2010	2012	Dodge	Dakota	-	Front	Conv	Hook slot 9x4	97053	V	95053	C4	-	-	-	21"
2016	2016	Ram	Powerwagon	-	Front	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2014	2018	Ram	Promaster	-	Driver Side	Beam	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2014	2018	Ram	Promaster	-	Passenger Side	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2018	Ram	Promaster City	Cargo Van	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2016	2018	Ram	Promaster City	Cargo Van	Passenger Side	Beam	PTB	97040	A	-	-	-	-	-	16"
1981	1986	Renault	R18i	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1983	1987	Renault	Alliance	-	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1987	1987	Renault	Alliance	GTA convertible	Front	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1984	1986	Renault	Encore	-	Front & Rear	Conv	Pin Arm	97045	V	-	-	-	-	-	18"
1972	1980	Renault	Gordini	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1972	1979	Renault	R 15, 17	including Gordini Submodel	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1975	1984	Rolls Royce	Camarque	-	Front	Conv	Pin Arm	97043	V	-	-	-	-	-	17"
1992	1992	Rolls Royce	Corniche II	-	Driver Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	1992	Rolls Royce	Corniche II	-	Passenger Side	Conv	Hook 9x3	97035	V	95035	C1	96135	Locking Clip	-	14"
1981	1988	Rolls Royce	Silver Sour	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2006	Saab	9-2X	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2006	Saab	9-2X	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1999	2003	Saab	42250	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2008	2011	Saab	9-3 Convertible	-	Front	Beam	I&L	97055	A	-	-	-	-	-	22"
2004	2007	Saab	9-3 Convertible	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2004	2007	Saab	9-3 Convertible	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1999	2003	Saab	9-3 Convertible	-	Front	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2006	2007	Saab	9-3 SportCombi	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2006	2007	Saab	9-3 SportCombi	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2008	2010	Saab	9-5 Sportwagon	-	Front	Beam	GEN2D I Bayonet	97053	C	-	-	-	-	-	21"
2000	2007	Saab	9-5 Sportwagon	-	Driver Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2000	2007	Saab	9-5 Sportwagon	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2005	2009	Saab	9-7X	-	Front	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
1994	1998	Saab	900	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1994	1998	Saab	900	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1979	1993	Saab	900	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1991	1994	Saab	900	Convertible	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1986	1998	Saab	9000	-	Front & Rear	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2008	2009	Saturn	Astra	-	Front Left	Beam	Pin & Hook	97055	B	-	-	-	-	-	22"
2008	2009	Saturn	Astra	-	Front Right	Beam	Pin & Hook	97045	B	-	-	-	-	-	18"
2008	2009	Saturn	Aura	-	Front Left	Beam	PTB	97060	A	-	-	-	-	-	24"
2008	2009	Saturn	Aura	-	Front Right	Beam	PTB	97053	A	-	-	-	-	-	21"
2007	2007	Saturn	Aura	-	Front Left	Beam	I&L	97060	A	-	-	-	-	-	24"
2007	2007	Saturn	Aura	-	Front Right	Beam	I&L	97053	A	-	-	-	-	-	21"
2003	2007	Saturn	Ion	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2007	Saturn	Ion	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2003	2007	Saturn	Ion Quad Coupe	-	Front Left	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2007	Saturn	Ion Quad Coupe	-	Front Right	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2005	Saturn	L300	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2005	Saturn	L / LW Series	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2003	Saturn	LS, LS1, LS2	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2003	Saturn	LW1, LW2 Wagon	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2007	2009	Saturn	Outlook	-	Front Left	Beam	PTB	97060	A	-	-	-	-	-	24"
2007	2009	Saturn	Outlook	-	Front Right	Beam	PTB	97053	A	-	-	-	-	-	21"
2005	2007	Saturn	Relay	-	Front Left	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2005	2007	Saturn	Relay	-	Front Right	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2005	2007	Saturn	Relay	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"

PIAA

YEAR (Range)									SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE		WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
1991	2003	Saturn	SC, SL, SW Series	-	Front Left	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
1991	2003	Saturn	SC, SL, SW Series	-	Front Right	Conv	Hook 9x3		97053	V	95053	C1	96153	Locking Clip	-	21"
1993	2003	Saturn	SC, SL, SW Series	-	Rear	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2007	2010	Saturn	Sky	-	Front Left	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2007	2010	Saturn	Sky	-	Front Right	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2009	Saturn	Vue	-	Front Left	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2008	2009	Saturn	Vue	-	Front Right	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2007	Saturn	Vue	-	Front Left	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2007	Saturn	Vue	-	Front Right	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
1997	2001	Saturn / Gm	EV-1	-	Front	Conv	Hook slot 9x3/9x4		97055	V	95055	C1	96155	Locking Clip	-	22"
2013	2016	Scion	FR-S	-	Driver Side	Hybrid	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2013	2016	Scion	FR-S	-	Passenger Side	Hybrid	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
2016	2016	Scion	iA	-	Driver Side	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2016	Scion	iA	-	Passenger Side	Conv	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
2016	2016	Scion	iM	-	Driver Side	Hybrid	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2016	Scion	iM	-	Passenger Side	Hybrid	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2012	2015	Scion	iQ	-	Driver Side	Hybrid	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2012	2015	Scion	iQ	-	Passenger Side	Hybrid	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2011	2016	Scion	tC	-	Driver Side	Hybrid	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2011	2016	Scion	tC	-	Passenger Side	Hybrid	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2010	Scion	tC	-	Driver Side	Conv	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2005	2010	Scion	tC	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2004	2006	Scion	xA	-	Driver Side	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2004	2006	Scion	xA	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2008	2015	Scion	xB	-	Driver Side	Hybrid	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2015	Scion	xB	-	Passenger Side	Hybrid	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
2008	2014	Scion	xD	-	Driver Side	Hybrid	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2014	Scion	xD	-	Passenger Side	Hybrid	Hook 9x3		97035	V	95035	C1	96135	Locking Clip	-	14"
2017	2018	Smart	Fortwo	-	Driver Side	Beam	GEN2D I Bayonet		97050	C	-	-	-	-	-	20"
2017	2018	Smart	Fortwo	-	Passenger Side	Beam	GEN2D I Bayonet		97050	C	-	-	-	-	-	20"
2016	2016	Smart	Fortwo	-	Driver Side	Beam	GEN2D I Bayonet		97050	C	-	-	-	-	-	20"
2016	2016	Smart	Fortwo	-	Passenger Side	Beam	GEN2D I Bayonet		97035	C	-	-	-	-	-	14"
2007	2015	Smart	Fortwo	Coupe, Cabriolet, Electric Drive	Driver Side	Beam	I&L		97055	A	-	-	-	-	-	22"
2007	2015	Smart	Fortwo	Coupe, Cabriolet, Electric Drive	Passenger Side	Beam	I&L		97053	A	-	-	-	-	-	21"
2005	2006	Smart	Fortwo	-	Front	Conv	Hook 9x3		97053	V	95053	C1	96153	Locking Clip	-	21"
1987	1988	Sterling	825	-	Front	Conv	Hook slot 9x3/9x4		97048	V	95048	C1	96148	Locking Clip	-	19"
1989	1991	Sterling	827	-	Front & Rear	Conv	Hook slot 9x3/9x4		97048	V	95048	C1	96148	Locking Clip	-	19"
2003	2006	Subaru	Baja	-	Driver Side	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2006	Subaru	Baja	-	Passenger Side	Conv	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2016	Subaru	BRZ	-	Driver Side	Hybrid	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2013	2016	Subaru	BRZ	-	Passenger Side	Hybrid	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
2016	2018	Subaru	CrossTrek	-	Driver Side	Conv	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2016	2018	Subaru	CrossTrek	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2014	2018	Subaru	Forester	Including XT	Driver Side	Hybrid	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2014	2018	Subaru	Forester	Including XT	Passenger Side	Hybrid	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
2009	2013	Subaru	Forester	-	Driver Side	Hybrid	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2013	Subaru	Forester	-	Passenger Side	Hybrid	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2006	2008	Subaru	Forester	-	Driver Side	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2006	2008	Subaru	Forester	-	Passenger Side	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2003	2005	Subaru	Forester	-	Driver Side	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2005	Subaru	Forester	-	Passenger Side	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2003	2003	Subaru	Forester	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1998	2002	Subaru	Forester	-	Driver Side	Conv	Hook slot 9x3/9x4		97053	V	95053	C1	96153	Locking Clip	-	21"
1998	2002	Subaru	Forester	-	Passenger Side	Conv	Hook slot 9x3/9x4		97048	V	95048	C1	96148	Locking Clip	-	19"
1998	2002	Subaru	Forester	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
2012	2018	Subaru	Impreza	Incl WRX / Excl. WRX STI	Driver Side	Conv	Hook		97065	V	-	-	-	-	-	26"
2012	2018	Subaru	Impreza	Incl WRX / Excl. WRX STI	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2017	2017	Subaru	Impreza	Inlc. Hatch Back	Driver Side	Beam	Gen2V5		97065	F	-	-	-	-	-	26"
2017	2017	Subaru	Impreza	Inlc. Hatch Back	Passenger Side	Beam	Gen2V5		97040	F	-	-	-	-	-	16"
2012	2016	Subaru	Impreza	WRX STI (Incl. Limited)	Driver Side	Hybrid	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2012	2016	Subaru	Impreza	WRX STI (Incl. Limited)	Passenger Side	Hybrid	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2010	2011	Subaru	Impreza	-	Driver Side	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2011	Subaru	Impreza	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2010	2011	Subaru	Impreza	WRX STI (Incl. Limited & Special Edition)	Driver Side	Hybrid	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2011	Subaru	Impreza	WRX STI (Incl. Limited & Special Edition)	Passenger Side	Hybrid	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2009	2009	Subaru	Impreza	-	Driver Side	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2009	2009	Subaru	Impreza	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2008	2008	Subaru	Impreza	-	Driver Side	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2008	2008	Subaru	Impreza	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2007	Subaru	Impreza	-	Driver Side	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2007	Subaru	Impreza	-	Passenger Side	Conv	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
2002	2003	Subaru	Impreza	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1993	2001	Subaru	Impreza	-	Driver Side	Conv	Hook slot 9x3/9x4		97053	V	95053	C1	96153	Locking Clip	-	21"
1993	2001	Subaru	Impreza	-	Passenger Side	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
1993	2001	Subaru	Impreza	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1989	1995	Subaru	Justy	-	Driver Side	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1995	Subaru	Justy	-	Passenger Side	Conv	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
1990	1992	Subaru	Justy	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
2015	2018	Subaru	Legacy	-	Driver Side	Hybrid	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2015	2018	Subaru	Legacy	-	Passenger Side	Hybrid	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
2010	2014	Subaru	Legacy	-	Driver Side	Hybrid	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2014	Subaru	Legacy	-	Passenger Side	Hybrid	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2009	Subaru	Legacy	-	Driver Side	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2009	Subaru	Legacy	-	Passenger Side	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2000	2004	Subaru	Legacy	-	Driver Side	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2004	Subaru	Legacy	-	Passenger Side	Conv	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2004	Subaru	Legacy	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1995	1999	Subaru	Legacy	-	Driver Side	Conv	Hook slot 9x3/9x4		97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1999	Subaru	Legacy	-	Passenger Side	Conv	Hook slot 9x3/9x4		97048	V	95048	C1	96148	Locking Clip	-	19"
1995	1999	Subaru	Legacy	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1990	1994	Subaru	Legacy	-	Driver Side	Conv	Hook slot 9x3/9x4		97050	V	95050	C1	96150	Locking Clip	-	20"
1990	1994	Subaru	Legacy	-	Passenger Side	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
1990	1994	Subaru	Legacy	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
2010	2018	Subaru	Outback	-	Driver Side	Hybrid	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2018	Subaru	Outback	-	Passenger Side	Hybrid	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
2005	2009	Subaru	Outback	-	Driver Side	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2005	2009	Subaru	Outback	-	Passenger Side	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2000	2004	Subaru	Outback	-	Driver Side	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2004	Subaru	Outback	-	Passenger Side	Conv	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2004	Subaru	Outback	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1992	1997	Subaru	SVX	-	Driver Side	Conv	Hook slot 9x3/9x4		97055	V	95055	C1	96155	Locking Clip	-	22"
1992	1997	Subaru	SVX	-	Passenger Side	Conv	Hook slot 9x3/9x4		97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1997	Subaru	SVX	-	Rear	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2008	2014	Subaru	Tribeca	-	Passenger Side	Conv	Hook		97050	V	-	-	-	-	-	20"
2012	2018	Subaru	WRX	-	Driver Side	Conv	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2012	2018	Subaru	WRX	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2013	2018	Subaru	WRX STI	-	Driver Side	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2013	2018	Subaru	WRX STI	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2013	2015	Subaru	XV Crosstrek	-	Driver Side	Conv	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2015	Subaru	XV Crosstrek	-	Passenger Side	Conv	Hook 9x3		97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2007	Suzuki	Aerio	Inc. Sedan, SX	Front Left	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2002	2007	Suzuki	Aerio	Inc. Sedan, SX	Front Right	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2009	2010	Suzuki	Equator	-	Front Left	Conv	Hook		97060	V	-	-	-	-	-	24"
2009	2010	Suzuki	Equator	-	Front Right	Conv	Hook		97045	V	-	-	-	-	-	18"
1995	2003	Suzuki	Esteem	Inc. Wagon	Front Left	Conv	Hook slot 9x3/9x4		97050	V	95050	C1	96150	Locking Clip	-	20"
1995	2003	Suzuki	Esteem	Inc. Wagon	Front Right	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2004	2008	Suzuki	Forenza	-	Front Left	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2008	Suzuki	Forenza	-	Front Right	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2006	2013	Suzuki	Grand Vitara	-	Front	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2005	Suzuki	Grand Vitara	-	Front	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2004	Suzuki	Grand Vitara	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
2010	2012	Suzuki	Kizashi	-	Front	Hybrid	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2012	Suzuki	Kizashi	-	Rear	Hybrid	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2008	Suzuki	Reno	-	Front Left	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2008	Suzuki	Reno	-	Front Right	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2008	Suzuki	Reno	-	Rear	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1998	Suzuki	Sidekick	-	Front	Conv	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
1989	1998	Suzuki	Sidekick	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
2007	2010	Suzuki	SX4	-	Front Left	Conv	Hook 9x3		97065	V	95065	C1	96165	Locking Clip	-	26"
2007	2010	Suzuki	SX4	-	Front Right	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1995	2002	Suzuki	Swift	-	Front Left	Conv	Hook slot 9x3/9x4		97050	V	95050	C1	96150	Locking Clip	-	20"
1995	2002	Suzuki	Swift	-	Front Right	Conv	Hook slot 9x3/9x4		97048	V	95048	C1	96148	Locking Clip	-	19"
1995	2002	Suzuki	Swift	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1989	1994	Suzuki	Swift	-	Front Left	Conv	Hook slot 9x3/9x4		97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1994	Suzuki	Swift	-	Front Right	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
1989	1994	Suzuki	Swift	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
1999	2004	Suzuki	Vitara	-	Front	Conv	Hook slot 9x3/9x4		97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2004	Suzuki	Vitara	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
2004	2006	Suzuki	Verona	-	Front Left	Conv	Hook 9x3		97055	V	95055	C1	96155	Locking Clip	-	22"
2004	2006	Suzuki	Verona	-	Front Right	Conv	Hook 9x3		97050	V	95050	C1	96150	Locking Clip	-	20"
1996	1998	Suzuki	X-90	-	Front Left	Conv	Hook 9x3		97043	V	95043	C1	96143	Locking Clip	-	17"
1996	1998	Suzuki	X-90	-	Front Right	Conv	Hook 9x3		97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2009	Suzuki	XL-7	-	Front Left	Conv	Hook 9x3		97060	V	95060	C1	96160	Locking Clip	-	24"
2007	2009	Suzuki	XL-7	-	Front Right	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2005	2006	Suzuki	XL-7	-	Front	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2001	2004	Suzuki	XL-7	-	Front	Conv	Hook 9x3		97048	V	95048	C1	96148	Locking Clip	-	19"
2001	2004	Suzuki	XL-7	-	Rear	Conv	Hook 9x3		97038	V	95038	C1	96138	Locking Clip	-	15"
2018	2018	Tesla	S	-	Driver Side	Beam	PTB		97065	A	-	-	-	-	-	26"

PIAA

YEAR (Range)								SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2018	2018	Tesla	S	-	Passenger Side	Beam	PTB	97045	A	-			-	-	18"
2012	2015	Tesla	S	-	Driver Side	Beam	PTB	97070	A	-	-	-	-	-	28"
2012	2015	Tesla	S	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
2008	2011	Tesla	Roadster	-	Front	Conv	Hook	97065	V	-	-	-	-	-	26"
2010	2018	Toyota	4Runner	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2010	2018	Toyota	4Runner	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2003	2009	Toyota	4Runner	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2003	2009	Toyota	4Runner	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	2002	Toyota	4Runner	-	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2018	2018	Toyota	4Runner	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2018	2018	Toyota	4Runner	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2013	2018	Toyota	Avalon	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2018	Toyota	Avalon	-	Passenger Side	Hybrid	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2005	2012	Toyota	Avalon	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2005	2012	Toyota	Avalon	-	Passenger Side	Beam	I&L	97050	A	-	-	-	-	-	20"
2000	2004	Toyota	Avalon	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2000	2004	Toyota	Avalon	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1995	1999	Toyota	Avalon	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	1999	Toyota	Avalon	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2018	2018	Toyota	C-HR	-	Driver Side	Hybrid	PTB	97065	A	-	-	-	-	-	26"
2018	2018	Toyota	C-HR	-	Passenger Side	Hybrid	PTB	97040	V	-	-	-	-	-	16"
2018	2018	Toyota	Camry	Inc. Hybrid	Driver Side	Hybrid	Hook 9x4	97065	V	-	-	-	Locking Clip	-	26"
2018	2018	Toyota	Camry	Inc. Hybrid	Passenger Side	Hybrid	Hook 9x4	97043	V	-	-	-	Locking Clip	-	17"
2012	2017	Toyota	Camry	Inc. Hybrid	Driver Side	Hybrid	Hook 9x3	97065	V	-	-	-	Locking Clip	-	26"
2012	2017	Toyota	Camry	Inc. Hybrid	Passenger Side	Hybrid	Hook 9x3	97045	V	-	-	-	Locking Clip	-	18"
2007	2011	Toyota	Camry	-	Driver Side	Hybrid	Hook 9x3	97060	V	-	-	-	Locking Clip	-	24"
2007	2011	Toyota	Camry	-	Passenger Side	Hybrid	Hook 9x3	97050	V	-	-	-	Locking Clip	-	20"
2002	2006	Toyota	Camry	-	Driver Side	Conv	Hook 9x3	97060	V	-	-	-	Locking Clip	-	24"
2002	2006	Toyota	Camry	-	Passenger Side	Conv	Hook 9x3	97048	V	-	-	-	Locking Clip	-	19"
1997	2001	Toyota	Camry	-	Driver Side	Conv	Hook 9x3	97053	V	-	-	-	Locking Clip	-	21"
1997	2001	Toyota	Camry	-	Passenger Side	Conv	Hook 9x3	97048	V	-	-	-	Locking Clip	-	19"
1992	1996	Toyota	Camry	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	-	-	-	Locking Clip	-	21"
1992	1996	Toyota	Camry	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	-	-		Locking Clip	-	19"
2000	2005	Toyota	Celica	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2000	2005	Toyota	Celica	-	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2000	2005	Toyota	Celica	-	Rear	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
1994	1999	Toyota	Celica	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1994	1999	Toyota	Celica	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1994	1999	Toyota	Celica	-	Rear	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2009	2018	Toyota	Corolla	Inc. iM	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2009	2018	Toyota	Corolla	Inc. iM	Passenger Side	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2002	2008	Toyota	Corolla	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2002	2008	Toyota	Corolla	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	2001	Toyota	Corolla	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	2001	Toyota	Corolla	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1996	Toyota	Corolla	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2000	2005	Toyota	Echo	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2007	2014	Toyota	FJ Cruiser	-	Driver Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2008	2018	Toyota	Highlander	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2008	2018	Toyota	Highlander	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2001	2007	Toyota	Highlander	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2007	Toyota	Highlander	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2013	2018	Toyota	Land Cruiser	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2013	2018	Toyota	Land Cruiser	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2008	2011	Toyota	Land Cruiser	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2008	2011	Toyota	Land Cruiser	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2007	Toyota	Land Cruiser	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2000	2007	Toyota	Land Cruiser	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2000	2007	Toyota	Land Cruiser	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1998	1999	Toyota	Land Cruiser	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1997	Toyota	Land Cruiser	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1999	Toyota	Land Cruiser	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2018	2018	Toyota	Land Cruiser	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2018	2018	Toyota	Land Cruiser	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2009	2014	Toyota	Matrix	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2009	2014	Toyota	Matrix	-	Passenger Side	Hybrid	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2003	2008	Toyota	Matrix	-	Driver Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2003	2008	Toyota	Matrix	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1995	Toyota	MR2	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1995	Toyota	MR2	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2000	2006	Toyota	MR2 Spyder	-	Driver Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2006	Toyota	MR2 Spyder	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1992	1999	Toyota	Paseo	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1999	Toyota	Paseo	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1995	Toyota	Pickup	-	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2010	2015	Toyota	Prius	including Plug in Hybrid	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2010	2015	Toyota	Prius	including Plug in Hybrid	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2004	2009	Toyota	Prius	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2004	2009	Toyota	Prius	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2001	2003	Toyota	Prius	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2001	2003	Toyota	Prius	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2018	2018	Toyota	Prius	Inc. Prime	Driver Side	Hybrid	PTB	97070	A	-	-	-	-	-	28"
2018	2018	Toyota	Prius	Inc. Prime	Passenger Side	Hybrid	PTB	97040	A	-	-	-	-	-	16"
2012	2018	Toyota	Prius C	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2012	2018	Toyota	Prius C	-	Passenger Side	Hybrid	Hook 9x3	97035	V	-	-	96135	Locking Clip	-	14"
2016	2017	Toyota	Prius C	Inc. Prime	Driver Side	Beam	Gen2V5	97070	F	-	-	-	-	-	28"
2016	2017	Toyota	Prius C	Inc. Prime	Passenger Side	Beam	Gen2V5	97040	F	-	-	-	-	-	16"
2012	2016	Toyota	Prius V	including Plug in Hybrid	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2012	2016	Toyota	Prius V	including Plug in Hybrid	Passenger Side	Hybrid	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2013	2018	Toyota	RAV4	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2013	2018	Toyota	RAV4	-	Passenger Side	Hybrid	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2006	2012	Toyota	RAV4	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2006	2012	Toyota	RAV4	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2001	2005	Toyota	RAV4	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2001	2005	Toyota	RAV4	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1996	2000	Toyota	RAV4	-	Driver Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1996	2000	Toyota	RAV4	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2013	2014	Toyota	RAV4 EV	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2013	2014	Toyota	RAV4 EV	-	Passenger Side	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2008	2018	Toyota	Sequoia	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2008	2018	Toyota	Sequoia	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2001	2007	Toyota	Sequoia	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2011	2018	Toyota	Sienna	-	Driver Side	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2011	2018	Toyota	Sienna	-	Passenger Side	Hybrid	Hook 9x3	97050	V	-	-	96150	Locking Clip	-	20"
2004	2010	Toyota	Sienna	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2004	2010	Toyota	Sienna	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2006	2010	Toyota	Sienna	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1998	2003	Toyota	Sienna	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1998	2003	Toyota	Sienna	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1998	2003	Toyota	Sienna	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
2004	2008	Toyota	Solara	-	Driver Side	Conv	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2004	2008	Toyota	Solara	-	Passenger Side	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
1999	2003	Toyota	Solara	-	Driver Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
1999	2003	Toyota	Solara	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1994	1998	Toyota	Supra	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1994	1998	Toyota	Supra	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1994	1998	Toyota	Supra	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1993	1998	Toyota	T100 Pickup	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
2016	2018	Toyota	Tacoma	-	Driver Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2018	Toyota	Tacoma	-	Passenger Side	Hybrid	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2005	2015	Toyota	Tacoma	-	Driver Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2005	2015	Toyota	Tacoma	-	Passenger Side	Conv	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	2004	Toyota	Tacoma	-	Front	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1991	1999	Toyota	Tercel	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2007	2018	Toyota	Tundra	-	Driver Side	Beam	I&L	97065	A	-	-	-	-	-	26"
2007	2018	Toyota	Tundra	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2000	2006	Toyota	Tundra	-	Front	Conv	Hook 9x3	97048	V	95048	C1	96148	Locking Clip	-	19"
2009	2015	Toyota	Venza	-	Driver Side	Hybrid	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2009	2015	Toyota	Venza	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2017	2018	Toyota	Yaris	Inc. iA	Driver Side	Hybrid	Hook 9x4	97055	V	-	-	-	-	-	22"
2017	2018	Toyota	Yaris	Inc. iA	Passenger Side	Hybrid	Hook 9x4	97043	V	-	-	-	-	-	17"
2012	2016	Toyota	Yaris	-	Front (single blade)	Hybrid	Hook 9x3	97070	V	-	-	96170	Locking Clip	-	28"
2007	2011	Toyota	Yaris	-	Driver Side	Conv	Hook 9x3	97065	V	-	-	96165	Locking Clip	-	26"
2018	2018	Volkswagen	Atlas	-	Driver Side	Beam	PTB	97065	B	-	-	-	-	-	26"
2018	2018	Volkswagen	Atlas	-	Passenger Side	Beam	PTB	97055	B	-	-	-	-	-	22"
2017	2018	Volkswagen	Beetle	-	Driver Side	Beam	PTB	97055	B	-	-	-	-	-	22"
2017	2018	Volkswagen	Beetle	-	Passenger Side	Beam	PTB	97055	B	-	-	-	-	-	22"
2012	2016	Volkswagen	Beetle	-	Driver Side	Beam	PTB	97053	B	-	-	-	-	-	21"
2012	2016	Volkswagen	Beetle	-	Passenger Side	Beam	PTB	97053	B	-	-	-	-	-	21"
1998	2011	Volkswagen	Beetle	Inc Cabrio	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1998	2011	Volkswagen	Beetle	Inc Cabrio	Passenger Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1995	2002	Volkswagen	Cabrio	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	2002	Volkswagen	Cabrio	-	Passenger Side	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1985	1993	Volkswagen	Cabriolet	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2013	2016	Volkswagen	CC	-	Driver Side	Beam	PTB	97060	B	-	-	-	-	-	24"
2013	2016	Volkswagen	CC	-	Passenger Side	Beam	PTB	97048	B	-	-	-	-	-	19"
2009	2012	Volkswagen	CC	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2009	2012	Volkswagen	CC	-	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
1990	1995	Volkswagen	Corrado	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1990	1995	Volkswagen	Corrado	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"

PIAA

YEAR (Range)								SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
1974	1981	Volkswagen	Dasher	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Volkswagen	E Golf	-	Driver Side	Beam	PTB	97065	B	-	-	-	-	-	26"
2016	2018	Volkswagen	E Golf	-	Passenger Side	Beam	PTB	97045	B	-	-	-	-	-	18"
2007	2015	Volkswagen	Eos	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2007	2015	Volkswagen	Eos	-	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
1995	2004	Volkswagen	Eurovan	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	2004	Volkswagen	Eurovan	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1995	2004	Volkswagen	Eurovan	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1992	1994	Volkswagen	Eurovan	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1992	1994	Volkswagen	Eurovan	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1987	1993	Volkswagen	Fox	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1987	1993	Volkswagen	Fox	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2015	2018	Volkswagen	Golf	Incl. Alltrack	Driver Side	Beam	PTB	97065	B	-	-	-	-	-	26"
2015	2018	Volkswagen	Golf	Incl. Alltrack	Passenger Side	Beam	PTB	97045	B	-	-	-	-	-	18"
2007	2014	Volkswagen	Golf	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2007	2014	Volkswagen	Golf	-	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
1993	2006	Volkswagen	Golf	-	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1993	2006	Volkswagen	Golf	-	Passenger Side	Conv	Hook slot 9x4	97048	V	95048	C3	-	-	-	19"
1985	1992	Volkswagen	Golf	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1985	1992	Volkswagen	Golf	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2015	2018	Volkswagen	Golf GTI	-	Driver Side	Beam	PTB	97065	B	-	-	-	-	-	26"
2015	2018	Volkswagen	Golf GTI	-	Passenger Side	Beam	PTB	97045	B	-	-	-	-	-	18"
2007	2014	Volkswagen	Golf GTI	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2007	2014	Volkswagen	Golf GTI	-	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
2006	2006	Volkswagen	Golf GTI	-	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
2006	2006	Volkswagen	Golf GTI	-	Passenger Side	Conv	Hook slot 9x4	97048	V	95048	C3	-	-	-	19"
2016	2018	Volkswagen	Golf R/ R Touch	-	Driver Side	Beam	PTB	97065	B	-	-	-	-	-	26"
2016	2018	Volkswagen	Golf R/ R Touch	-	Passenger Side	Beam	PTB	97045	B	-	-	-	-	-	18"
2016	2018	Volkswagen	Golf SportWagen TSI	-	Driver Side	Beam	PTB	97065	B	-	-	-	-	-	26"
2016	2018	Volkswagen	Golf SportWagen TSI	-	Passenger Side	Beam	PTB	97045	B	-	-	-	-	-	18"
2011	2018	Volkswagen	Jetta	-	Driver Side	Beam	PTB	97060	B	-	-	-	-	-	24"
2011	2018	Volkswagen	Jetta	-	Passenger Side	Beam	PTB	97048	B	-	-	-	-	-	19"
2011	2015	Volkswagen	Jetta Sportwagen	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2011	2015	Volkswagen	Jetta Sportwagen	-	Driver Side	Beam	PTB	97048	A	-	-	-	-	-	19"
2006	2010	Volkswagen	Jetta	Inc. Wagon	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2006	2010	Volkswagen	Jetta	Inc. Wagon	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
1993	2005	Volkswagen	Jetta	Inc. Wagon	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1993	2005	Volkswagen	Jetta	Inc. Wagon	Passenger Side	Conv	Hook slot 9x4	97048	V	95048	C3	-	-	-	19"
1993	2005	Volkswagen	Jetta	Inc. Wagon	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1980	1992	Volkswagen	Jetta	Inc. Wagon	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2012	2018	Volkswagen	Passat	-	Driver Side	Beam	PTB	97060	B	-	-	-	-	-	24"
2012	2018	Volkswagen	Passat	-	Passenger Side	Beam	PTB	97048	B	-	-	-	-	-	19"
2006	2010	Volkswagen	Passat	Inc. Wagon	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2006	2010	Volkswagen	Passat	Inc. Wagon	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
2002	2005	Volkswagen	Passat	Inc. Wagon	Driver Side	Beam	Pin & Hook	97053	B	-	-	-	-	-	21"
2002	2005	Volkswagen	Passat	Inc. Wagon	Passenger Side	Beam	Pin & Hook	97048	B	-	-	-	-	-	19"
2002	2005	Volkswagen	Passat	Inc. Wagon	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1997	2001	Volkswagen	Passat	Inc. Wagon	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1997	2001	Volkswagen	Passat	Inc. Wagon	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1997	2001	Volkswagen	Passat	Inc. Wagon	Rear	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1990	1996	Volkswagen	Passat	Inc. Wagon	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1990	1996	Volkswagen	Passat	Inc. Wagon	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1990	1996	Volkswagen	Passat	Inc. Wagon	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2004	2006	Volkswagen	Phaeton	-	Driver Side	Beam	Pin & Hook	97060	B	-	-	-	-	-	24"
2004	2006	Volkswagen	Phaeton	-	Passenger Side	Beam	Pin & Hook	97053	B	-	-	-	-	-	21"
1982	1988	Volkswagen	Quantum	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2008	2008	Volkswagen	R32	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2008	2008	Volkswagen	R32	-	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
2006	2009	Volkswagen	Rabbit	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2006	2009	Volkswagen	Rabbit	-	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
1975	1984	Volkswagen	Rabbit	-	Front & Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2009	2012	Volkswagen	Routan	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2009	2012	Volkswagen	Routan	-	Passenger Side	Conv	Hook 9x3	97050	V	95050	C1	96150	Locking Clip	-	20"
2011	2012	Volkswagen	Routan	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1986	1989	Volkswagen	Scirocco	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1986	1989	Volkswagen	Scirocco	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1975	1985	Volkswagen	Scirocco	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1975	1985	Volkswagen	Scirocco	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2017	2018	Volkswagen	Tiguan	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2017	2018	Volkswagen	Tiguan	-	Passenger Side	Beam	PTB	97053	A	-	-	-	-	-	21"
2009	2016	Volkswagen	Tiguan	-	Driver Side	Beam	PTB	97060	A	-	-	-	-	-	24"
2009	2016	Volkswagen	Tiguan	-	Passenger Side	Beam	PTB	97053	A	-	-	-	-	-	21"
2004	2015	Volkswagen	Touareg	-	Front	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
1992	1994	Volkswagen	Transporter Bus	-	Front	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1985	1991	Volkswagen	Transporter Bus	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1985	1994	Volkswagen	Transporter Bus	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1968	1979	Volkswagen	Transporter Bus	-	Front	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
1980	1991	Volkswagen	Vanagon	-	Front	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1980	1991	Volkswagen	Vanagon	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1990	1993	Volvo	240	-	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1990	1993	Volvo	240	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1985	1992	Volvo	740	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1985	1985	Volvo	745	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1989	1990	Volvo	760, Wagon	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1986	1988	Volvo	760, Wagon	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1983	1985	Volvo	760, Wagon	-	Front	Conv	Hook slot 9x3/9x4	97048	V	95048	C1	96148	Locking Clip	-	19"
1987	1991	Volvo	780	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1993	1997	Volvo	850	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1993	1997	Volvo	850	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1993	1997	Volvo	850	-	Rear	Conv	Hook 9x3	97043	V	95043	C1	96143	Locking Clip	-	17"
1991	1995	Volvo	940	-	Front	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
1992	1997	Volvo	960	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2013	Volvo	C30	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2007	2013	Volvo	C30	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2006	2013	Volvo	C70	Inc. Convertible	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2006	2013	Volvo	C70	Inc. Convertible	Passenger Side	Beam	PTB	97048	A	-	-	-	-	-	19"
1998	2005	Volvo	C70	Inc. Convertible	Driver Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1998	2005	Volvo	C70	Inc. Convertible	Passenger Side	Conv	Hook slot 9x4	97053	V	95053	C3	-	-	-	21"
1984	1984	Volvo	DL, GLE	Inc. Wagon	Front	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2006	2010	Volvo	S40	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2006	2010	Volvo	S40	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2004	2005	Volvo	S40	-	Driver Side	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2004	2005	Volvo	S40	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2000	2003	Volvo	S40	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2000	2003	Volvo	S40	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2011	2018	Volvo	S60	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2011	2018	Volvo	S60	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2005	2009	Volvo	S60	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2005	2009	Volvo	S60	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2001	2004	Volvo	S60	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2001	2004	Volvo	S60	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
1998	2000	Volvo	S70	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1998	2000	Volvo	S70	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2007	2015	Volvo	S80	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2007	2015	Volvo	S80	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2004	2006	Volvo	S80	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2004	2006	Volvo	S80	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
1999	2003	Volvo	S80	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
1999	2003	Volvo	S80	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"
2016	2018	Volvo	S90	-	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2016	2018	Volvo	S90	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
1997	1998	Volvo	S90	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2000	2004	Volvo	V40	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2000	2004	Volvo	V40	-	Passenger Side	Conv	Hook slot 9x3/9x4	97050	V	95050	C1	96150	Locking Clip	-	20"
2000	2004	Volvo	V40	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2006	2011	Volvo	V50	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2006	2011	Volvo	V50	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2005	2005	Volvo	V50	-	Driver Side	Beam	Pin & Hook	97065	B	-	-	-	-	-	26"
2005	2005	Volvo	V50	-	Passenger Side	Beam	Pin & Hook	97050	B	-	-	-	-	-	20"
2015	2018	Volvo	V60	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2015	2018	Volvo	V60	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2008	2010	Volvo	V70	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2008	2010	Volvo	V70	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2005	2007	Volvo	V70	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2005	2007	Volvo	V70	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2001	2004	Volvo	V70	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2001	2004	Volvo	V70	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2001	2004	Volvo	V70	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
1998	2000	Volvo	V70	-	Driver Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1998	2000	Volvo	V70	-	Passenger Side	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
1998	2000	Volvo	V70	-	Rear	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
1997	1998	Volvo	V90	-	Front	Conv	Hook slot 9x3/9x4	97053	V	95053	C1	96153	Locking Clip	-	21"
2010	2018	Volvo	XC60	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2010	2018	Volvo	XC60	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2008	2016	Volvo	XC70	-	Driver Side	Beam	PTB	97065	A	-	-	-	-	-	26"
2008	2016	Volvo	XC70	-	Passenger Side	Beam	PTB	97050	A	-	-	-	-	-	20"
2005	2007	Volvo	XC70	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2005	2007	Volvo	XC70	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2003	2004	Volvo	XC70	-	Driver Side	Conv	Hook slot 9x3/9x4	97060	V	95060	C1	96160	Locking Clip	-	24"
2003	2004	Volvo	XC70	-	Passenger Side	Conv	Hook slot 9x3/9x4	97055	V	95055	C1	96155	Locking Clip	-	22"

PIAA

YEAR (Range)								SI-TECH	SI-TECH	SUPER	SUPER	AERO	AERO VOGUE		
Start	End	Make	MODEL	SUBMODEL	POSITION	OE BLADE	OE ARM TYPE	WIPER PN	ADAPTER	SILICONE	SILICONE	VOGUE	ADAPTER	NOTES	LENGTH
2003	2004	Volvo	XC70	-	Rear	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2016	2018	Volvo	XC90	-	Driver Side	Beam	Narrow PTB	97060	B	-	-	-	-	-	24"
2016	2018	Volvo	XC90	-	Passenger Side	Beam	Narrow PTB	97050	B	-	-	-	-	-	20"
2012	2015	Volvo	XC90	-	Driver Side	Beam	I&L	97060	A	-	-	-	-	-	24"
2012	2015	Volvo	XC90	-	Passenger Side	Beam	I&L	97055	A	-	-	-	-	-	22"
2003	2004	Volvo	XC90	-	Driver Side	Conv	Hook slot 9x4	97060	V	95060	C3	-	-	-	24"
2003	2004	Volvo	XC90	-	Passenger Side	Conv	Hook slot 9x4	97055	V	95055	C3	-	-	-	22"
2015	2018	Gmc	Yukon / Yukon XL	-	Passenger Side	Hybrid	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2018	2018	Kia	Stinger	-	Driver Side	Conv	Hook 9x3	97065	V	95065	C1	96165	Locking Clip	-	26"
2018	2018	Kia	Stinger	-	Passenger Side	Conv	Hook 9x3	97045	V	95045	C1	96145	Locking Clip	-	18"
2008	2018	Lincoln	Navigator	-	Passenger Side	Conv	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2017	2018	Mitsubishi	Outlander Sport	-	Driver Side	Hybrid	Hook 9x3	97060	V	95060	C1	96160	Locking Clip	-	24"
2017	2018	Mitsubishi	Outlander Sport	-	Passenger Side	Hybrid	Hook 9x3	97053	V	95053	C1	96153	Locking Clip	-	21"
2018	2018	Tesla	S	-	Driver Side	Beam	PTB	97070	A	-	-	-	-	-	28"
2018	2018	Tesla	S	-	Passenger Side	Beam	PTB	97045	A	-	-	-	-	-	18"
2012	2016	Land Rover	LR4	-	Front	Beam	Hook 9x3	97055	V	95055	C1	96155	Locking Clip	-	22"
2012	2016	Land Rover	LR4	-	Rear	Conv	Hook 9x4	97040	V	95040	C3	96140	Locking Clip	-	16"
2018	2019	Jeep	Wrangler	JK	Driver Side	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2018	2019	Jeep	Wrangler	JK	Passenger Side	Conv	Hook 9x3	97038	V	95038	C1	96138	Locking Clip	-	15"
2018	2019	Jeep	Wrangler	Gladiator, JL	Driver Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"
2018	2019	Jeep	Wrangler	Gladiator, JL	Passenger Side	Conv	Hook 9x3	97040	V	95040	C1	96140	Locking Clip	-	16"